

# NOBLE·PRO

## ELITE E10i

### USER'S MANUAL

noble-pro.com

#### Treadmill Base

Model No: NPE78850E10bnf

Serial No: \_\_\_\_\_

Locate the serial number on the front of the treadmill base.

#### Treadmill Screen

Model No: NPE78851E10is

Serial No: \_\_\_\_\_

Locate the serial number on the back of the treadmill screen.

### CUSTOMER CARE

For technical support,  
please visit:

[noble-pro.com/help](http://noble-pro.com/help)

### CAUTION


Read all precautions and instructions in this manual before using this equipment. Save this manual for future reference.



# TABLE OF CONTENTS

ABOUT THE PRODUCT .....	5
ASSEMBLY .....	7
HOW TO USE THE TREADMILL .....	11
HOW TO MOVE THE TREADMILL .....	15
HOW TO LEVEL THE TREADMILL .....	15
MAINTENANCE .....	15
TROUBLESHOOTING .....	18
EXPLODED DRAWING 1 .....	20
EXPLODED DRAWING 2 .....	22
PARTS LIST .....	23
ORDERING REPLACEMENT PARTS .....	25
WARRANTY .....	25

## WARNING LABELS



---

## IMPORTANT PRECAUTIONS

**WARNING:** To reduce the risk of burns, fire, electric shock, or injury to persons, read all these **IMPORTANT** precautions and instructions in this manual and all warnings on your treadmill before using the treadmill. NoblePro Ltd assumes no responsibility for personal injury or property damage sustained by or using this product.

1. It is the owner's responsibility to ensure that all users of this treadmill are accurately informed of all warnings and precautions.
2. Before beginning any exercise program, consult your physician. This is **IMPORTANT** for persons over age 35 or persons with pre-existing health conditions.
3. Use the treadmill only as prescribed in this manual.
4. The treadmill is intended for home-use only. Do not use the treadmill in any commercial, rental or institutional setting.
5. Keep the treadmill in a secure, dry, well-ventilated area (above 5 °C) away from moisture and dust. Do not put the treadmill outside, under a covered patio or near water.
6. Place the treadmill on a level surface, with at least 8 ft. (2.4 m) of clearance behind it and 2 ft. (0.6 m) on either side. Do not place the treadmill on any surface that blocks air openings. To protect the floor or carpet from damage, place a mat under the treadmill.
7. Always keep pets and children under age 12 away from the treadmill.
8. The treadmill should be used only by persons weighing 396 lbs (180 kg) or less.
9. Never allow more than one person on the treadmill at a time.
10. Wear appropriate activewear and trainers while using the treadmill. Be aware that loose clothing could become caught on the treadmill. Never use the treadmill with bare feet, only socks or sandals.
11. Keep fingers, hair and clothing away from the moving running belt.
12. Do not operate the treadmill where aerosol products are used or where oxygen is being administered.
13. Plug the power cord into a surge suppressor (not included) and plug the surge suppressor into an appropriate outlet. To avoid overloading the circuit, do not plug other electrical devices into the surge suppressor or an outlet on the same circuit (low-power devices such as phone chargers will not cause an issue).
14. Use only a surge suppressor / circuit breaker that meets all the specifications in this manual. Failure to use a properly functioning surge suppressor could result in damage to the control system of the treadmill. If the control system is damaged, the running belt may slow, accelerate, or stop unexpectedly, resulting in a fall and severe injury.
15. Keep the power cord and the surge suppressor away from heated surfaces.
16. Never try to move the running belt while the power is turned off. Do not operate the treadmill if the power cord or plug is damaged or if the treadmill is not working properly. (See MAINTENANCE AND TROUBLESHOOTING if there are issues with the treadmill.)
17. Read, understand, and test the emergency stop procedure before using the treadmill (see HOW TO TURN ON THE POWER). Always wear the safety clip while using the treadmill.
18. Always stand on the side rails when starting or stopping the running belt. Always hold the handrails while using the treadmill  
Note: When a person is walking on the treadmill, the treadmill's noise level will increase.
19. To avoid static shock, wear natural fabrics. If there is a build-up of static, check that the plug and electric are earthed correctly.
20. The treadmill is capable of high speeds. Adjust the speed in small increments to avoid sudden surges in speed.
21. The heart rate monitor is NOT a medical device. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The heart rate monitor is intended only as an exercise aid in determining general heart rate trends.
22. Never leave the treadmill unattended while it is running. Always remove the safety key, press the red power switch into the off position, and unplug the power cord when the treadmill is not in use.
23. Do not attempt to move the treadmill until it is fully assembled. (See ASSEMBLY and HOW TO MOVE THE TREADMILL.)


24. Do not insert any objects into any openings on the treadmill.  
25. Inspect and properly tighten all parts of the treadmill regularly.  
26. Over-exercising may result in serious injury or death. If you feel faint, if you become short of breath or experience pain while exercising, please stop immediately.

27. **DANGER:** Always unplug the power cord immediately after use, before cleaning the treadmill and before performing the maintenance and adjustment procedures described in this manual. Never remove the motor cover unless instructed to do so by an authorized NoblePro Ltd representative. Additional servicing, other than the procedures in this manual, should be performed by an authorized service representative only.

## ABOUT THE PRODUCT


Thank you for selecting the NoblePro® E10i treadmill. The NoblePro® E10i treadmill offers an impressive selection of features designed to make your workouts at home more effective and enjoyable.

For your benefit, read this manual carefully before using the treadmill. If you have questions after reading this manual, please see the front cover of this manual. To help us assist you, please note the product model number(s) before contacting us. Before reading further, please review the drawing below and familiarize yourself with the labelled parts.




Max User Weight	180 kg
Dimensions (LxWxH)	2048 x 955 x 1545mm
Running Area	1555x580mm
Speed Range	1.0-22km/h
Incline levels	0-16 %
Machine Weight	117 N.W.: kg / 132 G.W. kg

## Box content



## Assembly kit



Description	QTY
1. M8*20 Screws	16
2. Ø8 Washers	18
3. R8 Washers	18
4. M5*12 Screws	4
5. M8*40 Screws	2
5mm Allen Key	1
8mm Allen Key	1
Star Screwdriver	1

# ASSEMBLY

## ATTENTION

- Assembly requires two persons
- Assemble in a clean and level area
- Before assembly, take parts out but do not dispose of any material until complete

Avoid using power tools


Left parts are marked as "L".

The right parts are marked as "R."

The treadmill might be coated by light oil to preserve it from rusting.

1. Register your product. Go to [noble-pro.com/product-registration](http://noble-pro.com/product-registration)
2. Download the latest User's Manual from [noble-pro.com/support](http://noble-pro.com/support)

Note: If you are unable to register online, please submit a technical ticket with NoblePro technical support for assistance at [noble-pro.com/technical-support-request/](http://noble-pro.com/technical-support-request/)




3. Identify the communication cable (28) located in the base frame.

Next, identify the right upright post (63). Have a second person hold the right upright post close to the base frame.


Then, feed the communication cable through the right upright post.

Place the right upright post into the base frame. Make sure not to pinch any cables.




4. Place the right upright post (63) into the base frame (1).

Then loosely fasten the post using 4 x M8\*20(64) and 1 x M8\*40 (65) screws with a flat washer (14) and spring washer (15) to the base frame.



5. Place the left upright post (62) into the base frame (1).


Then loosely fasten the post using 4 x M8\*20(64) and 1 x M8\*40 (65) screws with a flat washer (14) and spring washer (15) to the base frame.



6. Locate the communication wire (67) at the back of the Console on the right side of the console frame.


Connect the communication wire (67) to the communication wire (28). Place the console frame over the uprights.

**Note: Be careful not to crush the wire; it should be clear of edges.**






7. Use 4 x M8\*20 (64) screws with a flat washer (14) and spring washer (15) to fasten the right uprights to the Console. Lightly fasten all screws until all screws have been aligned.



8. Use 4 x M8\*20 (64) screws with a flat washer (14) and spring washer (15) to fasten the left uprights to the Console. Lightly fasten all screws until all screws have been aligned.


Tighten all screws in step 4 and 8.



9. Place the console screen assembly on the console base. Connect the console connections:


- A to A,
- B to B
- C to C
- D to D
- E to E

**Note:** The connector will make a "click" sound when secured. Gently pull them to check they do not separate.




10. Place the wires inside the base frame smoothly.

Use 4 x M5\*12 (6) screws to fasten the console screen assembly to the console base.



11. Place the motor insert cover on both the left (7) and right (8) upright post bases.



12. It is imperative to ensure that all parts are tightened before using the treadmill. It is advisable to place a protective mat under the treadmill and not onto a slippery, uneven surface.

**Information:** The tools provided can also be used for treadmill maintenance.

---

## HOW TO USE THE TREADMILL

### CONNECTING THE POWER CORD


#### Use a Surge Suppressor

The treadmill can be damaged by sudden voltage changes in your home's power. Voltage surges, spikes, and noise interference can result from weather conditions or other appliances being turned on or off. To decrease the risk of damaging the treadmill, use a surge suppressor that complies with or exceeds UL 1449 or BS 1363 requirements. The surge suppressor must be electrically rated for 240 volts AC and a minimum of 13 amps.

Failure to use a properly functioning surge suppressor could result in damage to the control system of the treadmill and serious injury to users.

#### Plug in the power cord


The treadmill must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for an electric current to reduce the risk of electric shock. Plug the power cord into a surge suppressor and plug the surge suppressor into an appropriate outlet that is properly installed and grounded in accordance with all local rules and regulations. The outlet must be on a nominal 240-volt circuit capable of carrying 16 or more amps. To avoid overloading the circuit, do not plug other electrical devices, except for low power devices such as cell phone chargers, into the surge suppressor or an outlet on the same circuit.



### HOW TO TURN ON THE POWER

**IMPORTANT:** If the treadmill has been exposed to cold temperatures, allow it to warm to room temperature before turning on the power. If you do not do this, you may damage the console displays or other electrical components.

Plug in the power cord. Next, locate the power switch on the treadmill frame near the power cord. Press the power switch into the "on" position.




Main switch

### HOW TO USE THE SAFETY KEY


The safety key is designed to bring the treadmill to a stop if disconnected. Insert the key into the Console as indicated, and securely attach the clip to your clothing.

**IMPORTANT:** The treadmill will not function without the safety key being placed in the Console.



## HOW TO USE THE CONSOLE

**IMPORTANT** Always keep your treadmill's software up to date. The latest user manual is available [noble-pro.com/support](http://noble-pro.com/support)



## HOW TO SET UP YOUR TREADMILL


The treadmill console will require setting up before use. Follow the below instructions:

### 1. Connect the treadmill to WiFi

The treadmill needs to be connected to WiFi to ensure your software is up to date. To connect the treadmill to WiFi, see page 13.

### 2. Update software

Once the treadmill is connected to the internet, open the System Updates app. This system will check for any operating system updates and provide an option to update, if a later version is available.




The user interface can be updated by going to Dashboard>Settings>Advanced>Software Version.

For the latest instructions refer to [noble-pro.com/e10i/updates](http://noble-pro.com/e10i/updates)

## CONNECTING TO WIFI

The following steps will guide you through how to connect your treadmill to WiFi.

1. On the home page, touch the WiFi icon.



2. Ensure the WiFi is enabled
3. Select the WiFi network from the available network list.
4. Enter the correct network password.
5. Verify that the network is connected.

## CONNECTING TO BLUETOOTH

To find out more about Bluetooth capabilities, go to [noble-pro.com/bluetooth/](http://noble-pro.com/bluetooth/)

## HOW TO NAVIGATE USING THE TOUCH SCREEN

The main touch screen navigation controls are built into the top bar for ease of use. The key functions have been explained below:



### Back button

It takes you to the previous screen



### Home button

It takes you back to the home screen




### Menu hider

Hides all the menus to enable the use of the full screen

## USING THE TREADMILL HANDGRIP HEART RATE MONITOR


The treadmill has built in handgrip heart rate monitors so please ensure to remove the protective plastic from the handgrips before use. For the most accurate heart rate reading, hold onto the handrails and avoid movement for 15 seconds or more.



## IMPORTANT: Read HOW TO TURN ON THE POWER (see page 11) DANGER: Stand on side rails when starting the treadmill

### START

1. Press the START button on the Console or the screen, and the belt will start to move.



As you exercise, change the speed of the running belt as desired by pressing the speed increase and decrease buttons. Each time you press one of the buttons, the speed setting, will change by 0.1 km/h; if you hold down the button, the speed setting will change rapidly. Note: After you press the button, it may take a moment for the running belt to reach the selected speed setting.

2. Change the incline of the treadmill as desired. To change the treadmill's incline, press the incline increase and decrease button on the Console or screen. Each time you press one of the buttons, the treadmill will gradually adjust to the selected incline setting.
3. Measure your heart rate if desired. You can measure your heart rate using the handgrip heart rate monitor.

To measure your heart rate, stand on the side rails, hold the pulse bar with your palms on the metal contacts, avoid moving your hands. When your pulse is detected, a heart symbol will appear, and your current heart rate will be shown. For the most accurate heart rate reading, continue to hold the contacts for about 15 seconds.

4. To stop the running belt, press the STOP button on the Console or screen. The running belt will slowly come to a stop. You will be asked if you want to stop the session or resume the workout.


Step onto the side rails and press the STOP button again. If the machine is turned off at an incline and you will hear the incline motor resetting to zero. Wait for the incline motor to stop completely before switching it off at the wall. Next, remove the safety key from the Console and put it in a secure place. When you are finished using the treadmill, press the power switch into the off position and unplug the power cord. **IMPORTANT:** If you do not do this, the treadmill's electrical components may wear prematurely.

---

## HOW TO MOVE THE TREADMILL

**Warning: Two persons are required to move the treadmill.**



1. Ensure the treadmill on level ground.
2. When handling, lift the end of the treadmill and then use the treadmill roller at the front to slowly move the treadmill.
3. Once in a suitable position, slowly lower the rear of the treadmill until it is resting on the ground.



---

## HOW TO LEVEL THE TREADMILL

1. Level the treadmill by adjusting the feet on the back of the treadmill.
2. Once adjusted, lock the nut to secure the feet into place



---

## MAINTENANCE

For more information on maintaining your treadmill go to [noble-pro.com/maintenance/](http://noble-pro.com/maintenance/)

### CLEANING

Regularly clean the treadmill and keep the running belt clean and dry. First, press the power switch into the "OFF" position and unplug the power cord. Wipe exterior parts of the treadmill with a damp cloth and a small amount of mild soap.

**IMPORTANT:** Do not spray liquids directly onto the treadmill. To avoid damage to the Console, keep liquids away from the Console. Then, thoroughly dry the treadmill with a soft towel.


### BELT LUBRICATION

Belt lubricating should be undertaken every 300 km or 3 months, whichever comes first. The running belt is lubricated with a high-performance silicone lubricant to reduce the friction between the running belt and the running board. If the lubrication is inadequate, the belt will not operate smoothly.

Before checking the lubrication on your treadmill belt, remove the safety key and UNPLUG THE POWER CORD. Run your finger along the underside of the belt. If there is no lubricant residue on your finger's lubrication is needed.

To add lubrication to the running belt, remove the lubrication cover (36) and add 15ml of silicon lubricant per side. Turn the treadmill on using easy start mode and let it run for 10 mins at 12 km/h. Repeat the process until there is an even film of lubricant on the running belt.

**IMPORTANT:** Excessive lubrication might result in the running belt or transition belts slipping and loss of drive.



### ADJUSTING THE RUNNING BELT

If the running belt is off centre, remove the safety key and **UNPLUG THE POWER CORD**.

If the running belt has shifted to the left (viewed from the back), use the 6mm hex key to turn the left idler roller screw clockwise  $\frac{1}{2}$  a turn; if the running belt has shifted to the right (viewed from the back), turn the right idler roller screw clockwise  $\frac{1}{2}$  a turn.


Then, plug in the power cord, insert the safety key and run the treadmill for a few minutes. Repeat until the running belt is centred.

**CAUTION:** Be careful not to overtighten the running belt as it might reduce the bearings' longevity.

### Tightening of the running belt

If the running belt slips when walked on, first remove the key and **UNPLUG THE POWER CORD**.

Using the 6 mm hex key, turn both idler roller screws a  $\frac{1}{4}$  of a turn clockwise at a time until you can lift each edge of the running belt 3 to 4 inches (8 to 10 cm) off the running board.





Be careful to keep the running belt centred. Then, plug in the power cord, insert the safety key, and carefully walk on the treadmill for a few minutes. Repeat until the running belt is sufficiently tightened.



## Loosening the running belt

**IMPORTANT:** If the running belt is overtightened, treadmill performance may decrease, and the running belt and bearings might become damaged.

To loosen the running belt, first, remove the key and UNPLUG THE POWER CORD. Then using the hex key, turn both idler roller screws a  $\frac{1}{4}$  a turn counter clockwise at a time until you can lift each edge of the running belt 3 to 4 inches (8 to 10 cm) off the walking board. Be careful to keep the running belt centred. Then, plug in the power cord, insert the safety key and run the treadmill for a few minutes. Repeat until the running belt is properly tightened.




## TROUBLESHOOTING

Issue	Possible Causes	Solution
The treadmill does not turn on	A No power	Plug in the power cable
	B Safety key not detected	Insert safety key
	C Faulty communication circuit	Check control panel and communication cables
	D Treadmill power switch in "OFF" position	Turn the power switch to the "ON" position
	E Blown fuse	Replace the fuse
The console screen does not display anything	The power cord is not connected	Connect the power cord and check the socket
	B The power switch is on the "OFF" position	Turn the power switch to the "ON" position
	C Power overload or damaged driver	Push the overload protection button. Replace the driver
	D Communication cable faulty	Replace the communication cable
	E Digital watch is damaged	Replace the digital watch
	F (LCD) backlight is not bright	Adjust, replace or repair the backlight
The treadmill display is missing characters	A An issue with the display connections	Repair or replace display they
	B The display is not fixed in position and sliding around	Repair or replace the splay
	C Faulty display driver IC	Repair or replace display driver IC
Treadmill running belt not moving smoothly	An Excessive resistance on the transmission system	Adjust the transmission parts and / or lubricate accordingly
	B Running belt is too tight	Loosen running belt
	C Running belt is too loose	Tighten running belt
	D Torque requirements too small or too high	Adjust the torque potentiometer accordingly
	E Lack of running belt lubrication	Lubricate the running belt as directed in the user manual
	F Motor belt is slipping	Tighten the motor belt
	G Over lubrication	Remove excessive lubrication on running belt and drive belt
Static shock	Static electricity is not being earthed	Ensure the plug earth quality is good
	B High static cloths used during exercise	Use natural material clothing during exercise
Buzzing noise	A Plug power is out of phase	Inspect the plug outlet phase quality
	B Incorrect voltage supply	Ensure the correct voltage is supplied to the treadmill


<b>Issue</b>	<b>Possible Causes</b>	<b>Solution</b>
Safety key	A Missing safety key	Place the safety key in the designated area
	B Faulty magnetic sensor	The safety key magnetic sensor is stuck. Repair or replace magnetic sensor.
Communication failure	A Communication cable faulty	Reconnect the communication cables
	B Damaged communication cable	Replace communication cable
	C Communication cable connection faulty	Replace effected cables
	D IC drive cable faulty	Replace the IC drive cable
Motor stalls	A Loose motor connection cables	Check wire connections are tight or replace the motor
	B Motor controller board faulty	Replace the IC drive
	C External ac voltage is too low	Undertake electrical supply troubleshooting where the treadmill is plugged in
Incline motor stalling	A Faulty incline motor connection	Check wire connections are tight or replace the motor
	B Faulty incline motor	Replace incline motor
	C Faulty IC drive	Replace the IC drive
Over-current protection	A Treadmill overloaded	Rotate the motor by hand and safely try again
	B Excessive friction in driver motors	Inspect and maintain transmission components
	C Motors damaged	Replace motor
	D Motor controller damaged	Replace IC drive
Motor error	A Motor cable connection faulty	plug machine line again
	B Motor is shorting internally	change the motor
	C Motor is idling	The motor current is too low. Replace the motor

# EXPLODED DRAWING 1





# EXPLODED DRAWING 2



## PARTS LIST

No. Part	Description	No. Part	Description
1	Base frame	51	Rear roller cover (left)
2	Dust shield	52	Rear roller cover (right)
3	Screw ST4. 8X16	53	Rear foot base
4	Screw M4X10	54	Foot
5	Motor cover	55	Absorption pad
6	Screw M5X12	56	Incline frame
7	Motor insert cover (left)	57	Incline frame shaft
8	Motor insert cover (right)	58	Screw M8X40
9	Motor front cover	59	Nylon wheel
10	Motor cover insert part	60	Nylon wheel axle sleeve
11	Motor cover mounting plate	61	Screw M10X60
12	Motor mount	62	Upright (left)
13	Screw M8X16	63	Upright (right)
14	Spring washerØ8×2.1	64	Screw M8X20
15	Washer Ø 8X1.6	65	Screw M8X40
16	Drive motor	66	Console frame
17	Screw M8X12	67	Communication cable (4 core wire)
18	WasherØ10×2	68	Heart rate mounting bracket
19	Nut M10	69	Screw M8X16
20	Bolt M8X55	70	Screen cover
21	Power inlet	71	Speaker
22	Screw ST2.9X8	72	Tablet bracket
23	Power cable	73	Touch screen
24	Power switch	74	AUX board
25	Screw M4X10	75	USB board
26	Motor Control Board (MCB)	76	Screen cover (front)

<b>No. Part</b>	<b>Description</b>	<b>No. Part</b>	<b>Description</b>
<b>27</b>	Power supply	<b>77</b>	Screen cover (rear)
<b>28</b>	Communication cable (4 core wire)	<b>78</b>	Fan
<b>29</b>	Incline motor	<b>79</b>	Air guide pt.1
<b>30</b>	Bolt M10X45	<b>80</b>	Air guide pt.2
<b>31</b>	Bolt M10X70	<b>81</b>	Console cover (top)
<b>32</b>	Running belt	<b>82</b>	Console cover (bottom)
<b>33</b>	Running board	<b>83</b>	Console controls cover (top)
<b>34</b>	Lubrication channel	<b>84</b>	Console controls cover (bottom)
<b>35</b>	Screw ST4.2X13	<b>85</b>	Heart rate cover
<b>36</b>	Lubrication cover	<b>86</b>	Heart rate contact cover (top)
<b>37</b>	Cushioning	<b>87</b>	Heart rate contact cover (bottom)
<b>38</b>	Absorption pad	<b>88</b>	Screw S4.2×25
<b>39</b>	Screw M8X45	<b>89</b>	Heart rate ring cover (left)
<b>40</b>	Nut M8	<b>90</b>	Heart rate ring cover (right)
<b>41</b>	Front roller assembly	<b>91</b>	Console arm (right)
<b>42</b>	Screw M10X35	<b>92</b>	Console arm (left)
<b>43</b>	Transmission belt	<b>93</b>	Safety key
<b>44</b>	Rear roller assembly	<b>94</b>	Power cable
<b>45</b>	Screw M10X85	<b>95</b>	Power cable
<b>46</b>	Foot rails		
<b>47</b>	Rail guide		
<b>48</b>	Screw ST4.2X16		
<b>49</b>	Upright cover (left)		
<b>50</b>	Upright cover (right)		



---

## ORDERING REPLACEMENT PARTS

To order replacement parts, please see the front cover of this manual. To help us assist you, be prepared to provide the following information when contacting us:

- the model number and serial number of the product
- the name of the product (see the front cover of this manual)
- the part number and description of the replacement part(s) (see the PARTS LIST page 22-23 and the EXPLODED DRAWINGS page 20-21)

---

## WARRANTY

Offered by NOBLEPRO LIMITED ("NoblePro")

All NoblePro products are warranted for use within a private, domestic, non-fee-paying environment. The warranties are non-transferable as they are only valid for the original owner (purchaser) of the equipment. The warranty will not apply if the product is used other than domestic use. It is not operated according to the operating manual supplied, or the product leaves the country it was supplied in. The warranties are subject to the product been used as intended and maintained and serviced as prescribed. Abuse or inappropriate use of the product will be excluded from the warranty.

### **NoblePro warrants this product to be free from defects in workmanship and material.**

The STANDARD WARRANTY is for a period of 12 months, if not registered. The STANDARD WARRANTY includes the frame of the equipment in question with its motor. The labour applicable here is also included.

When the product is purchased, it needs to be registered online at [noble-pro.com/product-registration](http://noble-pro.com/product-registration) within 30 days after purchase to qualify for the EXTENDED WARRANTY. For further information about your warranty, please go to [noble-pro.com/warranty/](http://noble-pro.com/warranty/).

All repairs or replacement needs to be authorized by NoblePro. NoblePro will not reimburse for any transport or courier service and arrange for the product to be collected either by NoblePro or a third party. The warranty is related to the delivery address of the client, and additional collection and delivery fees may be applicable due to the extended distance. The client consents to NoblePro to assess the product and repair it if required on the premises where the product is located. The client or any other party may not conduct any repair work on the machine other than the normal service and maintenance as per the operating manual supplied. The warranty excludes explicitly cases where the product was altered, modified, damaged or repaired by any party other than NoblePro. The warranty does not cover damage caused by fire, lightning, accidents, water damage (including humidity), pollution (such as fumes, dust and chemicals) or earthquakes.

The process to act on the warranty includes the notification of NoblePro, which include the nature of the problem encountered and the serial number of the equipment. If it is a minor repair, NoblePro may guide the client to rectify the matter. A charge will be levied to collect and deliver the product, but if the product was identified with a defect, this charge would be reimbursed when the product is fixed and returned to the customer.

NoblePro has the right to replace the product with a similar product in terms of condition and specifications of the product sold to the customer.

NoblePro is not responsible or liable for any expense, liability, loss, or proceeding whatsoever in respect of any personal injury related to the equipment or any damages, economic loss including loss of revenue, loss of enjoyment or training or any other consequential damages that are permitted by law.