



## 5

This BERG will make you jump, ride and fly the outdoors. With fresh air in your hair and this BERG at your side, you feel strong wherever you fly. Feel confident, even when the road ahead is bumpy. Feel at home, the moment you step outside. Because you know the sky is yours. And you are about to touch it.

# REGISTER YOUR BERG



Register your new
BERG product now,
unlock free extras
and become a
true BERGER via

BERG.com/registration

## CONTENT

What is in the box? 4 Make sure you have everything.

How to install it?
Follow the steps, easy as that.


What to know? 17 Warnings, info and warranty.

Ready to go!


The outdoors is yours. Enjoy it.

Although we know you can do it yourself please read the manual carefully and check out our instruction videos on YouTube.com/BERGtoys


## UNPAGKING




## INSTALLATION OF THE STALLATION OF THE STALLATION














## ENGLISH

## Warnings

This accessory is only suitable for assembly on the PlayBase Frame. Always read the PlayBase frame manual in combination with this manual.

- Read instructions prior to first use and keep for future reference!
- · Adult assembly required.
- · Not suitable for children under 36 months.
- Strangulation hazard a damaged net could lead to a risk of strangulation.
- · Adult supervision required.
- · Only for domestic use.
- Only for outdoor use.
- · Tighten the velcro straps tight against the frame.
- All velcro straps must be attached correctly and firmly to ensure a safe product.
- For general safety instructions of this accessory in combination with the PlayBase frame see section 2. Safety instruction of the PlayBase frame manual.
- We advise the removal and storage of this product during rain and the winter because the material will wear rapidly and fungus can appear inside the product.
- Do not climb in the soccer net.
- Do not climb on the frame when the soccer net is attached.

BERG or the dealer cannot be held responsible for improper use of this product. For safety reasons, unless BERG-approved, modifications or changes to the product are prohibited.

Only use this product as instructed in this manual. Any unauthorized use could result in serious injury to the user or damage the product.

### Inspection and maintance

To ensure the safety of the users of the product, the product has to be subjected to the safety inspections and maintenance instructions mentioned below. If not carried out regularly the product could become a hazard.

- · Check attachments for evidence of deterioration.
- Replace defective parts in accordance with the manufacturers' instructions.
- Any worn or replaced parts must be disposed according local guidelines. Pay attention to the environment.
- Check if all straps are correctly and firmly attached before each use.
- Missing or worn components must be replaced or repaired immediately. A damaged net could lead to a risk of strangulation.

## Warranty

Inappropriate use or faulty application of the product is explicitly forbidden and absolves the manufacturer of all liability. Modifications made by the customer to the original product (for example the adding of an accessory) shall be carried out according the instructions of the manufacturer.

The owner of this BERG product has the following warranty on this product:

- The product has a warranty of 3 years from the date of purchase.
- Parts that are liable to wear and tear and influences of weather are excluded from warranty.
- Check www.berg.com for extensive warranty regulations.

	Before each use	Monthly	Beginning of each season
Connection points	Check for visible damage	Check if connections are tight and tighten them if needed	Inspect the frame connections thoroughly
Soccer target net	Check condition	Check for wear and tear and replace if needed	Check for wear and tear and replace if needed





www.berg.com

49.90.20.13 | Rev: 1

Place Batch Number Sticker Here

I

