



PLAYBASE MANUAL



BERG



***WELCOME
TO OUR
WORLD***

***IT'S YOUR
NOW***

ME

'S

HI BERGER This BERG will make you jump, ride and fly the outdoors. With fresh air in your hair and this BERG at your side, you feel strong wherever you fly. Feel confident, even when the road ahead is bumpy. Feel at home, the moment you step outside. Because you know the sky is yours. And you are about to touch it.

REGISTER YOUR BERG



Register your new
BERG product now,
unlock free extras
and become a
true BERGER via
BERGtoys.com/registration

CONTENT

What is in the box? 4

Make sure you have everything.

How to install it? 9

Follow the steps, easy as that.

What to know? 23

Warnings, info and warranty.


Ready to go!

The outdoors is yours. Enjoy it.

Although we 
know you can
do it yourself 
please read the manual
carefully and check out
our instruction videos on
YouTube.com/BERGtoys

UNPACKING


TOP FRAME



PARTS
Page 5&6


ASSEMBLY
Page 9-12

TUMBLE







PARTS
Page 7
ASSEMBLY
Page 13

LADDER




PARTS
Page 8
ASSEMBLY
Page 14





20.10.00.01 **MEDIUM**







20.10.01.01 **LARGE**



20.11.00.01 **TUMBLE**




20.11.01.01 LADDER



INSTALLATION

1




TOP FRAME 2x




ON

2


2x




3



4






5




6

M:4x L:6x




7






8

TUMBLE




9






10





- Make sure the warnings stickers are facing outwards. **EN**
- Zorg ervoor dat de waarschuwingsstickers naar buiten gericht zijn. **NL**
- Achten Sie darauf, dass die Warmaufkleber nach außen gerichtet sind. **DE**
- Assurez-vous que les autocollants d'avertissement sont bien lisibles de l'extérieur. **FR**
- Asegúrate de que las adhesivos de advertencia estén orientados hacia afuera. **ES**
- Accertati che gli adesivi di avvertimento siano rivolti verso l'esterno. **IT**
- Sørg for, at advarselsmærkater vender udad. **DK**
- Se till att varningsdekaler är på utsidan. **SV**
- Sorg for at advarselsklistremerker vender utover. **NO**
- Varmista, että varoitukset ovat ulospäin. **FI**



11




12




13







Large




Medium







16




17




18





20




21







SWING HEIGHT ADJUSTMENT



EN Adjusting eight without lip. Ensure that the product hangs horizontal after adjustment of the ropes.

NL Stelacht zonder lip. Zorg ervoor dat het product horizontaal hangt na het verstellen van de touwen.

DE Einstellen der Achterhaken ohne Dorn. Stellen Sie sicher, dass das Produkt nach dem Einstellen der Seile horizontal hängt.

FR Ajuster les fixations sans les brides. Assurez-vous que le produit est suspendu horizontalement après le réglage des cordes.

ES Ajuste de altura sin borde. Asegúrate de que el producto cuelgue horizontalmente después de ajustar las cuerdas.

IT Regolazione otto senza bordo. Verifica che il prodotto penda orizzontalmente dopo aver regolato le corde.


DK Justering af otte uden læbe. Sørg for, at produktet hænger vandret efter justering af rebene.

SV Justering av åtta utan läpp. Se till att produkten hänger horisontalt sedan repen justerats.

NO Justering av åtte uten leppe. Sørg for at produktet henger vannrett etter justering av tauene.

FI Korkeuden säätäminen ilman reunusta. Varmista, että tuote roikkuu vaakatasossa köysien säätämisen jälkeen.

CLIMBING NET INSTALLATION



EN Adjusting eight with lip. Ensure that the climbing net ends are smaller than 10 cm after installation.

NL Stelacht met lip. Zorg ervoor dat de uiteinden van het klimnet korter zijn dan 10 cm na het installeren.

DE Einstellen der Achterhaken mit Dorn. Achten Sie darauf, dass die Kletternetzenden nach der Montage kürzer als 10 cm sind.

FR Ajuster les fixations avec les brides. Veillez à ce que les extrémités du filet d'escalade ne dépassent pas 10 cm après l'installation.

ES Ajuste de altura sin borde. Asegúrate de que los extremos de la red de escalada midan menos de 10 cm después de la instalación.


IT Regolazione otto con bordo. Verifica che le estremità della rete da arrampicata siano inferiori a 10 cm dopo l'installazione.

DK Justering af otte med læbe. Sørg for, at enderne på klatrenettet er mindre end 10 cm efter installationen.

SV Justering av åtta med läpp. Se till att lätternätets ändrar är mindre än 10 cm efter montering.

NO Justering av åtte med leppe. Sørg for at klatrenettene er mindre enn 10 cm etter installasjon.

FI Korkeuden säätäminen reunuksen kanssa. Varmista, että kiipeilyverkon päät ovat alle 10 cm pituiset asennuksen jälkeen.



INTENDED USE

EN Attention!

This manual is suitable for several types of use of the Playbase. Please check your intended use and when reading the manual, pay attention to which information applies to your Playbase combination. See the attached document for approved combinations. If you are not sure if your own combination is confirmed guidelines, please contact a BERG dealer.

NL Let op!

Deze handleiding is geschikt voor verschillende soorten gebruik van de Playbase. Ga bij het lezen van de handleiding na welk gebruik je voor ogen hebt, let op welke informatie van toepassing is op uw Playbase-combinatie.

Zie het bijgevoegde document voor goedgekeurde combinaties. Als je niet zeker weet of je eigen combinatie voldoet aan de voorschriften, neem dan contact op met een BERG dealer.

DE Achtung!

Dieses Handbuch eignet sich für verschiedene Arten der Verwendung der Playbase. Bitte prüfen Sie Ihren Verwendungszweck und achten Sie beim Lesen der Anleitung darauf, achten Sie darauf, welche Informationen für Ihre Ihre Playbase-Kombination zutreffen.

Im beigefügten Dokument finden Sie die zugelassenen Kombinationen. Wenn Sie nicht sicher sind, ob Ihre eigene Kombination den Vorschriften entspricht, wenden Sie sich bitte an einen BERG-Händler.

FR Attention!

Ce manuel est adapté à plusieurs types types d'utilisation du Playbase. Veuillez vérifier l'utilisation que vous souhaitez en faire et, lorsque vous lisez le manuel, faites attention aux informations qui s'appliquent à votre combinaison de Playbase. Consultez le document ci-joint pour connaître les combinaisons approuvées. Si vous n'êtes pas sûr que votre propre combinaison soit conforme aux directives, veuillez contacter un revendeur BERG.

ES ¡Atención!

Este manual es adecuado para varios tipos de uso de la Playbase. Compruebe el uso previsto y, al leer el manual, preste atención a la información que se aplica a su combinación Playbase. Consulte en el documento adjunto las combinaciones aprobadas. Si no está seguro de si su propia combinación cumple las directrices, póngase en contacto con un distribuidor de BERG.

IT Attenzione!

Questo manuale è adatto a diversi tipi di utilizzo della Playbase. Verificate l'uso che intendete farne e, leggendo il manuale, prestate attenzione a quali informazioni si applicano alla vostra combinazione di Playbase. Consultare il documento allegato per le combinazioni approvate. Se non si è sicuri che la propria combinazione sia conforme alle linee guida, contattare un rivenditore BERG.

DA Vær opmærksom!

Denne manual er velegnet til flere typer brug af Playbase. Tjek venligst din påtænkte brug, og når du læser manualen, skal du være opmærksom på, hvilke oplysninger der gælder for din Playbase-kombination. Se det vedhæftede dokument for godkendte kombinationer. Hvis du ikke er sikker på, om din egen kombination bekræfter retningslinjerne, bedes du kontakte en BERG-forhandler.

SV Observera!

Denna bruksanvisning är avsedd för flera olika typer av användning av Playbase. Kontrollera din avsedda användning och var uppmärksam på vilken information som gäller för din Playbase-kombination när du läser manualen. Se det bifogade dokumentet för godkända kombinationer. Om du inte är säker på om din egen kombination uppfyller riktlinjerna, kontakta en BERG-återförsäljare.

SV OBS!

Denne håndboken er egnet for flere typer typer bruk av Playbase. Kontroller hva du skal bruke den til, og vær oppmerksom på hvilken informasjon som gjelder for din Playbase-kombinasjon når du leser håndboken. Se vedlagte dokument for godkjente kombinasjoner. Hvis du er usikker på om din egen kombinasjon er i samsvar med retningslinjene, kan du kontakte en BERG-forhandler.

FI Huomio!


Tämä käyttöohje soveltuu useille Playbasen erityyppiseen käyttöön. Tarkista käyttötarkoituksesi ja kiinnitä käyttöohjetta lukiessasi huomiota siihen, mitkä tiedot koskevat Playbase-yhdistelmääsi.

Katso oheisesta asiakirjasta hyväksytyt yhdistelmät. Jos et ole varma, onko oma yhdistelmäsi ohjeiden mukainen, ota yhteyttä BERG-jälleenmyyjään.




Safe area of use


Minimal clearance for *Play*



Minimal clearance for *Sports*



Minimal clearance for *Lounge*



ENGLISH

Attention! This manual is suitable for several types of products. When reading the manual, pay attention to which information applies to your product.

Warnings

General warnings:

- The product should be assembled in accordance with the assembly instructions.
- Adult assembly required.
- Read instructions prior to first use and keep for future reference.
- For domestic use only.
- For outdoor use only.
- Falling hazard - frame height of 245 cm (8').
- Choking hazard - small parts in its unassembled state.
- Strangulation hazard - loose ropes can cause strangulation.
- The maximum user weight on the product is 100 kg (220 lbs).
- The maximum load for the entire product is 400 kg (880 lbs).
- The maximum user weight per accessory is indicated in that particular product manual.
- Usage of the product while under the influence of alcohol or drugs is prohibited.
- The product can become hot in direct sunlight, be careful.
- Keep fire and other heat sources away from the product.
- Do not use the product when it is wet.
- Objects and other obstacles that can interfere with using the product should be prohibited from the area of use.

Only add the add-ons referred to on the added "Allowed Combinations" document to the frame. Do not combine products of other manufacturers with this product because they may create safety hazards.

Play warnings:

- Not suitable for children under 3 years. Falling hazard – frame height of 245 cm. Strangulation hazard – loose ropes can cause strangulation. Choking hazard – small parts in its unassembled state. Continuous adult supervision required.
- The user age for the use of the BERG Playbase Baby seat (20.20.00.00) is 9 to 36 months.
- Continuous adult supervision required.
- It is prohibited to climb over the frame during all other activities on the product (e.g. climbing).



Sport warnings:

- Suitable for children from 14 years and older or overall height more than 140 cm (4' 7").
- Only use this product when your own medical condition allows it to use it safe.
- Avoid over-exertion when using the equipment.
- Only use the boxing bag at positions where 100 cm (40") movement space can be met.
- It is prohibited to use the climbing net when training with the boxing bag.



Lounge warnings:

- Continuous adult supervision required.
- Not suitable for children under 3 years
- Hammocks are not swing devices.
- It is forbidden to climb over the frame when a hammock is attached.



User guidelines

BERG or the dealer cannot be held responsible for improper use of this product. For safety reasons, unless BERG-approved, modifications or changes to the product are prohibited.

Only use this product as instructed in this manual. Any unauthorized use could result in serious injury to the user or damage the product.

Safe area of use *General*

Check page 18 for additional illustrations.

- The product must be placed level, ensuring a minimum clearance of at least 2,2 meters from any structure or obstructions such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.
- Place the product on an unpaved steady surface such as grass. Do not install your product over concrete, asphalt or any other hard surface.
- Objects and other obstacles that can interfere with using the product should be prohibited from the area of use.
- Position the product in a way that accessories (e.g. swings) are not oriented directly towards full exposure from the sun.

Safe installation

It is prohibited to make other combinations than the prescribed combinations listed on our website and in the attached "Allowed Combinations". The product should be assembled in accordance with the assembly instructions. Review the assembled product prior to first use.

Please be aware the product has fixings with self-locking nuts. These self-locking nuts are for single use only and must be replaced when dismantling and reinstalling the product.

- The product must be assembled according the detailed steps on pages 9-22.
- The product shall not be installed over concrete, asphalt or any other hard surface.
- The bottom frame must be buried according installation instructions in order to reduce tipping hazards. Pay special attention to the mandatory installation depth.
- The bolt indicated in step 21 of the Assembly Manual should be at ground level or lower to achieve the minimal installation depth.
- The adding of accessories must be carried out according to the manufacturer's instructions.
- When installing the climbing net, ensure that there is no risk of entrapment.

Safe use for *Play*

Check page 26 for additional illustrations.

- The minimum clearance between the swing element and the ground must be 35 cm (14").
- The minimum clearance between two separate swing elements must be 45 cm (18").
- The minimum clearance between the swing element and the frame must be 30 cm (12").
- The minimal clearance between single swing elements (rings, disc) must be 60 cm (24").
- Swing elements must be adjusted as explained in the Assembly Manual on page 23 to achieve the minimal clearances.
- The climbing net must be installed as explained on page 24 to avoid entrapments
- Do not combine any swinging elements with the Climbing Net M/L.
- Do not attach extra items to this product, such as ropes, chains, heavy cords or other items.
- Only add the add-ons mentioned in the attached document to the frame. Do not combine products of other manufacturers with this product because they may create safety hazards.

Safe use for *Sports*

Check page 26 for additional illustrations.

- Only use the boxing bag at positions where 100 cm (40") movement space can be met.

Safe use for *Lounge*


Check page 26 for additional illustrations.

- It is forbidden to climb over the frame when the hammock is attached.
- The hammock and all parts of the attachment must be removed if the frame is used with outdoor fitness equipment or toy accessories.
- Do not use the hammock / hanging seat if parts are damaged or lost.

Exercise instructions

The product can be used as outdoor fitness equipment for home use. Always perform any exercises in a controlled way. Do not perform any exercise which is

too hard for you. Here some exercise examples that will get you going:



Maintenance

To ensure the safety of the users of the product, the product has to be subjected to the safety inspections and maintenance instructions mentioned below. If the checks are not carried out regularly the product could overturn or otherwise become a hazard.

- There must be no objects / sharp objects on the floor underneath the unit and in the movement area.
- Check all nuts and bolts for tightness and tighten when required.
- Missing or worn components must be replaced or repaired immediately.
- Oil all metallic moving parts.

- Check all coverings for bolts and sharp edges and replace when required.
- Check swing seats, chains, ropes and other means of attachments for evidence of deterioration.
- Replace defective parts in accordance with the manufacturers' instructions.
- The swing joints are fixed on one side: Explicit attention should be paid to checking the suspension points and replacing them immediately if there is visible damage.
- Follow your local guidelines for the disposal of all materials.

	Before each use	Monthly	Beginning of each season
Frame, nuts & bolts	Check for visible damage	Check if connections are tight and tighten them if needed	Inspect the frame connections thoroughly
Suspension points	Inspect condition of suspension points. Replace immediately if needed	Oil the suspension points	Thorough inspection of suspension points. Replace immediately if needed
Accessories	Check condition	Check for wear and tear	Check for wear and tear and replace if needed

Warranty

Warranty period

BERG products are of excellent quality. To provide you with years of carefree fun on our products, BERG offers you a functionality warranty. A functionality warranty is a warranty regarding its functional use. Please consult the table below for the term of this warranty.

- Parts that are liable to wear and tear (such as ropes), the influences of weather (such as rust and discolouration) and foam parts are excluded from warranty.
- Check www.bergtoys.com for extensive warranty regulations.

Warranty conditions

The owner of the product can only claim a warranty by presenting the original receipt of the purchase. The warranty only applies to material and construction faults and with respect to this product or parts thereof.

Frame	10
Frame (after registration)	13
Components & accessories	3

The warranty becomes nul and void if:

- The product is used improperly and / or negligently.
- The product is improperly buried?
- The product is not assembled and maintained in accordance with the instruction manual.
- Technical repairs to the product are not carried out in a professional manner.
- Replacement parts do not correspond to the technical specifications of the product involved or are installed incorrectly.
- Parts mounted afterwards do not meet technical specifications of the product involved or have not been mounted correctly.
- Added parts or replaced parts are no official BERG spare parts or accessories.
- The product has been used for rental purposes or made available for use by a 3rd party.

LET'S GO!



www.bergtoys.com

49.90.20.09 | Rev: 02

Place Batch Number Sticker Here