


Assembly and Operating Instructions









FSUKTFMS5.01.01

SKU: TF-MS5

Content

1	GENERAL INFORMATION	8
1.1	Technical Data	8
1.2	Personal Safety	9
1.3	Set-Up Place	10
2	ASSEMBLY	11
2.1	General Instructions	11
2.2	Scope of Delivery	12
2.3	Assembly	17
3	STORAGE AND TRANSPORT	30
3.1	General Instructions	30
4	TROUBLESHOOTING, CARE AND MAINTENANCE	31
4.1	General Instructions	31
4.2	Faults and Fault Diagnosis	31
4.3	Maintenance and Inspection Calendar	32
5	DISPOSAL	32
6	RECOMMENDED ACCESSORIES	33
7	ORDERING SPARE PARTS	34
7.1	Serial Number and Model Name	34
7.2	Parts List	35
7.3	Exploded Drawing	37
8	WARRANTY	38
9	CONTACT	40

Dear customer,

Thank you for choosing quality training equipment from the TAURUS® brand. Taurus offers sports and fitness equipment for home users with high demands on quality, functionality and longevity. Also, Taurus is a well-known and experienced brand for equipping professional rooms for fitness studios and business customers. The focus of Taurus fitness equipment is on what matters most in sports: maximum performance! Therefore, the devices are developed in close consultation with athletes and sports scientists. Because athletes know best what makes perfect fitness equipment.

Further information can be found at www.fitshop.co.uk

Intended Use

The equipment may only be used for its intended purpose.

The equipment is only suitable for home use. The equipment is not suitable for semi-professional (e.g. hospitals, associations, hotels, schools, etc.) and commercial or professional use (e.g. fitness studios).

Legal Notice

Fitshop GmbH Europe's No. 1 for home fitness

International Headquarters Flensburger Straße 55 24837 Schleswig Germany Management:

Christian Grau

Sebastian Campmann

Dr. Bernhard Schenkel

No. HRB 1000 SL

Local Court Flensburg

European VAT Number: DE813211547

Disclaimer

© TAURUS is a registered brand of the company Fitshop GmbH. All rights reserved. Any use of this trademark without the explicit written permission of Fitshop is prohibited.

Product and manual are subject to change. Technical data can be changed without advance notice.



Europe's No.1 for Home Fitness

ABOUT THIS MANUAL

Please carefully read the entire manual before installation and first use. The manual will help you to quickly set up the system and explains how to safely use it. Make sure that all persons exercising with the equipment (especially children and persons with physical, sensory, mental or motor disabilities) are informed about this manual and its contents in advance. In case of doubt, responsible persons must supervise the use of the equipment.

Due to ongoing changes and software optimisations, the manual may have to be updated. If you notice any discrepancies during assembly or use, please refer to the manual uploaded to the webshop. The latest manual is always available there.



This equipment has been manufactured according to the latest safety knowledge. As far as possible, potential safety hazards which could cause injury have been eliminated. Make sure to carefully follow the instructions and that all parts are securely in place. If required, read through the instructions again to correct any mistakes.

Training devices must be classified according to accuracy and use. Accuracy classes are only applicable to devices that display training data.

Accuracy classes

Class A: high accuracy.
Class B: medium accuracy.
Class C: low accuracy.

The use classes explain the intended use of the training device.

Use classes

Class S (studio): professional and/or commercial use.

These training devices are intended for the use in training rooms of facilities such as sports clubs, school facilities, hotels, clubs and studios whose access and supervision is specifically regulated by the owner (person with legal responsibility).

Class H (home use): use at home.

These stationary training devices are intended for the use in private homes where access to the training device is regulated by the owner (person with legal responsibility).

Please pay close attention to the safety and maintenance instructions given here. The contract partner cannot be held liable for damage to health, accidents or damage to the equipment when it is not used in accordance with these instructions.

The following safety instructions may appear in this manual:

ATTENTION

This notice indicates potentially hazardous situations which, if not avoided, may result in property damage.

CAUTION

This notice indicates potentially hazardous situations which, if not avoided, may result in slight or minor injuries!

⚠ WARNING

This notice indicates potentially hazardous situations which, if not avoided, may result in death or serious injuries!

↑ DANGER

This notice indicates potentially hazardous situations which, if not avoided, will result in death or serious injuries!

(i) NOTICE

This notice indicates further useful information.

Retain these instructions in a safe place for future reference, maintenance or when ordering replacement parts.

1.1 Technical Data

Weight and dimensons:

Article weight (gross, including packaging): 136 kg

Article weight (net, without packaging): 108 kg

Packaging dimensions (L x W x H): 215 cm x 68.5 cm x 30.5 cm

Set-up dimensions (L x W x H): 152.5 cm x 133.8 cm x 222 cm

Maximum user weight: 130 kg

Cable material: Iron

Cover material: Nylon

Cable length: Cable 1: 219.3 cm, cable 2: 224 cm

Transmission ratio: 1:2

Use class:

1.2 Personal Safety

↑ DANGER

- + Before you start using the equipment, you should consult your physician that this type of exercise is suitable for you from a health perspective. Particularly affected are persons who: have a hereditary disposition to high blood pressure or heart disease, are over the age of 45, smoke, have high cholesterol values, are overweight and/or have not exercised regularly in the past year. If you are under medical treatment that affects your heart rate, medical advice is absolutely essential.
- + Note that excessive training can seriously endanger your health. Please also note that heart rate monitoring systems can be inaccurate. If you notice any signs of weakness, nausea, dizziness, pain, shortness of breath, or other abnormal symptoms, stop exercising immediately and seek advice from your doctor if necessary.
- + The owner must communicate all warnings and instructions to the user.

↑ WARNING

- + This equipment may not be used by children under the age of 14.
- + Children should not be allowed unsupervised access to the equipment.
- + Persons with disabilities must have a medical license and must be under strict observation when using the equipment.
- + The equipment is strictly for use by one person at a time.
- + Keep your hands, feet and other body parts, hair, clothing, jewellery and other objects well clear of moving parts.
- + During use, wear suitable sports clothing rather than loose or baggy clothing. When wearing sports shoes, make sure they have suitable soles, preferably made of rubber or other non-slip materials. Shoes with heels, leather soles, studs or spikes are unsuitable. Never exercise barefoot.
- + Always start each workout with a light warm-up and end with a cool-down phase.
- + Using the machine as a support during stretching exercises or attaching resistance bands, ropes or other accessories to it, may cause injuries.

CAUTION

- + If your equipment needs to be connected to the power supply with a mains cable, make sure that the cable is not a potential tripping hazard.
- + Make sure that nobody is within the range of motion of the equipment during training so as not to endanger you or other persons.
- + Be aware that if adjustment devices are left protruding, they may impede the user's movement.
- + The weights should remain in the user's field of vision during the entire exercise to prevent danger to third parties.

ATTENTION

+ Do not insert any objects of any kind into the openings of the device.

1.3 Set-Up Place

↑ WARNING

+ Do not place the equipment in main corridors or escape routes.

CAUTION

- + Choose a location in which to place the equipment such that there is enough free space/ clearance to the front, the rear and to the sides of the equipment.
- + The training room should be well ventilated during training and not be exposed to any draughts.
- + Choose the place in which to set up the equipment such that there is enough free space/ clearance to the front, the rear and to the sides of the equipment.
- + The free area in the direction from which the exercise equipment is accessed must be at least 0.6 m larger than the exercise area.
- + The set-up and mounting surface of the equipment should be flat, loadable and solid.
- + If your device is to be mounted on the wall/ceiling, make sure that you use the appropriate assembly material to avoid possible damages or personal injuries. The contractual partner accepts no liability for this.

► ATTENTION

- + The device may only be used in one building, in sufficiently tempered and dry rooms (ambient temperatures between 10°C and 35°C). The equipment should not be used outdoors or in rooms with high humidity (over 70%) like swimming pools.
- + A floor protective mat/equipment underlay can help to protect high-quality floor coverings (parquet, laminate, cork, carpets) from dents and sweat and can help to level out slight unevenness.
- + For Class S equipment, the exercise equipment may only be used in areas where access, supervision and control are specifically regulated by the owner.

MS5

2.1 General Instructions

⚠ DANGER

+ Do not leave any tools, packaging materials such as foils or small parts lying around, as otherwise there is a danger of suffocation for children. Keep children away from the equipment during assembly.

⚠ WARNING

+ Pay attention to the instructions attached to the equipment in order to reduce the risk of injuries.

CAUTION

- + Ensure to have sufficient room for movement in each direction during assembly.
- + The assembly of the equipment must be carried out by at least two adults. If in doubt, seek the help of a third technically skilled person.

► ATTENTION

+ To prevent damage to the equipment and the floor, assemble the equipment on a mat or packaging board.

(i) NOTICE


- + In order to make the assembly as simple as possible, some screws and nuts to be used can already be pre-assembled.
- + Ideally, assemble the equipment at its later set-up place.

2.2 Scope of Delivery


The scope of delivery consist of the following parts. At the beginning, check whether all parts and tools belonging to the device are included in the scope of delivery and whether damage has occurred. In the event of complaints, the contractual partner must be contacted directly.


⚠ CAUTION


If parts of the scope of delivery are missing or damaged, the assembly must not be carried out.




MS5










Pulley (18x)










37 Barbell rod sleeve






40 Short safety stopleft







41 Short safety stopright




45 Handle strap (2x)






43 Bull stick



Bicep rope



44 Carabiner (4x)

2.3 Assembly


Before assembly, take a close look at the individual assembly steps shown and carry out the assembly in the order given.

(i) NOTICE

- + First loosely screw all parts together and check that they fit properly. Tighten the screws using the tool only when you are instructed to do so.
- + If you have difficulty recognising the graphics, we recommend that you open and/or download the PDF instructions stored in the webshop on your end device (e.g. smartphone, tablet or PC). There you have the option of zooming in closer. Please note that the Adobe Acrobat Reader programme must be installed on your end device in order to open the file.


Step 1: Assembly of the Main Frame

- 1. Assemble one back column (4) to the right ground tube (2) with two screws (9), two spring washers (10) and two washers (6).
- 2. Assemble the other back column (4) to the left ground tube (3) with two screws (9), two spring washers (10) and two washers (6).
- 3. Assemble the middle lower connection tube (1) to the right and left ground tube (2 & 3) with four screws (5), eight washers (6) and four lock nuts (7).
- 4. Assemble the middle lower connection tube (1) to the back columns (4) with four screws (5), four washers (6), four large washers (8) and four lock nuts (7).




Step 2: Assembly of the Front Tubes and Sliding Sleeves

- 1. Assemble the right front tube (11) to the right ground tube (2) with two screws (5), four washers (6) and two lock nuts (7).
- 2. Assemble the left front tube (12) to the left ground tube (3) with two screws (5), four washers (6) and two lock nuts (7).
- 3. Attach the right sliding sleeve (13) to the right front tube (11).
- 4. Attach the left sliding sleeve (14) to the left front tube (12).




Step 3: Assembly of the Upper Connection Tube and Beams

- 1. Assemble the middle upper connection tube (17) to the right and left beam (15 & 18) with four screws (5), eight washers (6) and four lock nuts (7).
- 2. Assemble the right and left beam (15 & 18) to the back columns (4) with two beam joints (16), two screws (5), four washers (6) and two lock nuts (7).
- 3. Assemble the right and left beam (15 & 18) to the right and left front tube (11 & 12) with two screws (5), four washers (6) and two lock nuts (7).




Step 4: Assembly of the Upper Beam

1. Assemble the upper beam (19) to the right and left beam (15 & 18) with four screws (5), four large washers (8), four washers (6) and four lock nuts (7).



Step 5: Assembly of the Middle Tube

- Assemble the limited tube (20) to the middle lower connection tube (1) with two screws (9), two 1. spring washers (10) and two washers (6).
- Assemble the middle tube (21) to the middle lower connection tube (1) and middle upper connection tube (17) with two screws (5), four washers (6) and two lock nuts (7).
- Attach the barbell lift bars (23) and two spring collars (25) to the barbell lift piece (22) with one bolt (24) each.




Step 6: Assembly of the Wire and Pulley - Part 1

(i) NOTICE

The wire and pulleys must be assembled simultaneously.

- 1. Route the wire (26) between the two pulley brackets, over two pulleys (29) and attach the pulleys to the pulley brackets with one bolt (30), one pulley bar (31), two washers (6) and one lock nut (7) each. [A]
- 2. Route the wire (26) down around the pulley (27). [B]
- 3. Route the wire (26) up and over one pulley (29) and attach the pulley to the pulley bracket with one bolt (30), one pulley bar (31), two washers (6) and one lock nut (7). [C]
- 4. Route the wire (26) down and around two pulleys (29) and attach the pulleys to the pulley brackets with one bolt (30), two washers (6) and one lock nut (7) each. [D]
- 5. Route the wire (26) up and over two pulleys (29) and attach the pulleys to the pulley brackets with one bolt (30), one pulley bar (31), two washers (6) and one lock nut (7) each. [E]
- 6. Route the wire (26) down. [F]
- 7. Route the wire (26) up and over two pulleys (29) and attach the pulleys to the pulley brackets with one bolt (30), one pulley bar (31), two washers (6) and one lock nut (7) each. [G]
- 8. Route the wire (26) down and around two pulleys (29) and attach the pulleys to the pulley brackets with one bolt (28), two washers (6) and one lock nut (7) each. [H]
- 9. Route the wire (26) up and over one pulley (29) and attach the pulley to the pulley bracket with one bolt (30), one pulley bar (31), two washers (6) and one lock nut (7). [I]
- 10. Route the wire (26) down and aound the pulley (27). [J]
- 11. Route the wire (26) up and over two pulleys (29) and attach the pulleys to the pulley brackets with one bolt (30), one pulley bar (31), two washers (6) and one lock nut (7) each. [K]




Step 7: Assembly of the Wire and Pulleys - Part 2

① NOTICE


The wire and pulleys must be assembled simultaneously.

- 1. Assemble one end of the wire (32) to the right sliding sleeve (13) with one screw (9), two washers (6) and one lock nut (7).
- 2. Route the wire (32) down and around two pulleys (29) and attach the pulleys to the pulley brackets with one bolt (28), two washers (6) and one lock nut (7) each.
- 3. Route the wire (32) up around the pulley (29).
- 4. Assemble the other end of the wire (32) to the right ground tube (2) with one screw (9), two washers (6) and one lock nut (7).
- 5. Repeat these steps for the left side.



Step 8: Assembly of the Barbell Bars

1. Assemble six barbell bars (33) and six spring collars (25) to the back columns (4) with six screws (9), six spring washers (10) and six washers (6).




Step 9: Assembly of the Barbell Rod Sleeve and Hooks

- 1. Assemble the barbell rod sleeve (37) to the middle lower connection tube (1) with two screws (5), two large washers (8), two washers (6) and two lock nuts (7).
- 2. Attach four the short hooks (34) to the middle upper connection tube (17).

Load and Unload Weight Plates


A CAUTION

- + Make sure to always use some sort of weight collar when exercising with external weights.
- + Never store unused weight plates on the floor.
- + Store unused weight plates on a weight rack or respective storage horns.




Step 10: Assembly of the Safety Stops

- 1. Attach the left short safety stop (41), the left long safety stop (42) and two L pins (38) to the right front tube (12).
- 2. Attach the right short safety stop (40), the right long safety stop (39), the bull stick (43) and two L pins (38) to the left front tube (11).



Accessories



3.1 General Instructions

⚠ WARNING

- + The storage location should be chosen so that improper use by third parties or children can be prevented.
- + If your equipment does not have transportation wheels, the equipment must be disassembled before transportation.

ATTENTION

+ Make sure that the equipment is protected from moisture, dust and dirt in the selected storage location. The storage location should be dry and well ventilated and have a constant ambient temperature between 10°C and 35°C.

4.1 General Instructions

WARNING

+ Do not make any improper changes to the equipment.

A CAUTION

+ Damaged or worn components may affect your safety and the life of the equipment. Therefore, immediately replace damaged or worn components. In such a case, contact the contract partner. The equipment must not be used until it has been repaired. If necessary, use only original spare parts.

► ATTENTION

+ In addition to the instructions and recommendations for maintenance and care given here, additional service and/or repair work may be necessary; this must only be carried out by authorised service technicians.

4.2 Faults and Fault Diagnosis

The equipment undergoes regular quality controls during production. Nevertheless, faults or malfunctions may occur. Frequently, individual parts are responsible for these disturbances, an exchange is usually sufficient. Please refer to the following overview for the most common errors and how to correct them. If the equipment still does not function properly, contact your contract partner.

Fault	Cause	Solution
Grinding noises	Cables or pulleys do not run smoothly or are damaged	 Visual inspection of the cable routing or the pulley guide If damaged, replace the defective part
Cable without tension	Cable too loose	+ Check cable routing + Readjust cable tension
Squeaking & cracking noises	Screw connections loosened or too tight	+ Check or lubricate screw connections* + Check cable routing
Unit wobbles	+ Uneven ground+ Loose screw connections	+ Align unit + Tighten screw connections
Heavy draught	+ Weight holders/guide rods too dry+ Faulty cable routing	+ Lubricate guide rods* + Check cable routing

^{*} With a grease-free silicone oil or silicone spray.

4.3 Maintenance and Inspection Calendar

To avoid damage from body sweat, the equipment must be cleaned with a damp towel (no solvents!) after each training session.

The following routine tasks must be performed at the specified intervals:

Part	Weekly	Monthly	Quarterly
Cables	С	I	
Screw connections		I	
Pulleys and cable routing		I	
Legend: C = clean; I = inspect			

DISPOSAL

At the end of its operational life, this equipment cannot be disposed of in normal household waste. Instead, it must be disposed of via an recycling centre. Further information can be obtained from your local authority's recycling service.



The materials can be recycled as per their symbols. Through the reuse, recycling of materials or other forms of recovery of old equipment, you make an important contribution to the protection of the environment.

RECOMMENDED ACCESSORIES

To make your training experience even more efficient and pleasant, we recommend that you add suiting accessories to your fitness equipment. For training equipment like smith machines, weight benches or racks this could for example be a **floor mat**, which makes your fitness equipment stand more securely and also protects the floor from sweat but it could be also **additional weights**, **handles**, **foot straps** for leg exercises or **triceps ropes**. For some smith machines, there are also optional addons such as **leg presses** that make your workout even more intense and comprehensive.

Our range of accessories offers the highest quality and makes training even better. If you would like to find out more about compatible accessories, please go to the detail page of the product in our webshop (the easiest way is to enter the article number in the search field above) and go to the recommended accessories on this page. Of course, you can also contact our customer service: by telephone, e-mail, in one of our branches or via our social media channels. We will be happy to advise you!



7.1 Serial Number and Model Name

In order to provide you with the best possible service, please have the model name, article number, serial number, exploded drawing and parts list ready. The corresponding contact options can be found in chapter 9 of this operating manual.


(i) NOTICE The serial number of y	our equipment is unique. It's located on a white sticker.
Enter the serial number in t	he appropriate field.
Serial number:	
Brand / Category:	
Taurus / multi gym	
Model Name:	
Taurus MS5 Multi Function	nal Cable Machine
SKU:	
TF-MS5	

7.2 Parts List

No.	Name	Specification	Qty.
1	3102 Middle lower connection tube	Assembly Part	1
2	3102 Right ground tube	Assembly Part	1
3	3102 Left ground tube	Assembly Part	1
4	3116 Back column weldment	Welding Part	2
5	Hexagon Head Screws	M10×70	28
6	Washer	φ10	102
7	Lock nut	M10	50
8	Large washer	φ30*φ10*3	10
9	Hexagon Head Screws	M10×25	16
10	Spring washer	φ10	12
11	3116 Stainless steel tube-front right	50*50*1.5	1
12	3116 Stainless steel tube-front left	50*50*1.5	1
13	3059 Sliding sleeve-right	Assembly Part	1
14	3059 Sliding sleeve	Assembly Part	1
15	3116 Beam-right	Assembly Part	1
16	3103 Beam joint	T4	2
17	3116 Middle upper connection tube	Assembly Part	1
18	3116 Beam-left	Assembly Part	1
19	3116 Upper beam	Assembly Part	1
20	3102 Limited tube	Assembly Part	1
21	3116 Middle stainless steel tube	50*50*1.5	1
22	3102 Barbell piece lift	Assembly Part	1
23	3102 Barbell lift bar	Assembly Part	2
24	Hexagon bolt	M8*10	2
25	Spring collar	φ50	8
26	Steel wire rope	φ5	1
27	Pulley bracket	Assembly Part	2
28	Hexagon Head Screws	M10×45	8
29	92 Pulley (powder sleeve)	φ92	18
30	Hexagon Head Screws	M10×50	10
31	Plastic pulley bar	T4	10

32	3102 Secure steel wire rope	Assembly Part	2
33	Plasstic barbell piece hanging bar	Assembly Part	6
34	3060 Short hook	Assembly Part	4
37	3000 Barbell rod sleeve	Welding Part	1
38	Fixed elastic rope L pin	φ17×250×77L	4
39	3080 Long safety stop	Assembly Part	1
40	3080 Short safety stop-left	Assembly Part	1
41	3080 Short safety stop-right	Assembly Part	1
42	3080 Long safety stop-right	Assembly Part	1
43	3000 Bull stick	Assembly Part	1
44	Carabiner	Assembly Part	4
45	Handle strap	Five rings	2
46	Bicep rope	φ28*690	1
47	Handle	Assembly Part	1

7.3 Exploded Drawing



WARRANTY

Products from TAURUS® are subject to strict quality control. However, if a fitness equipment purchased from us does not work perfectly, we take it very seriously and ask you to contact our customer service as indicated. We are happy to help you by phone via our service hotline.

Error Descriptions

Your fitness equipment is developed for long-term, high-quality training. However, should a problem arise, please first read the operating instructions. For further assistance, please contact your contract partner or call our service hotline. To ensure your problem is solved as quickly as possible, please describe the defect as exactly as possible.

In addition to the statutory warranty, we provide a warranty for every fitness equipment purchased from us according to the following provisions.

Your statutory rights are not affected.

Warrantee

The warrantee is the first/original buyer.

Warranty periods

The following warranty periods begin on delivery of the fitness equipment.

Warranty period

The warranty periods, shown on our web shop, begin on delivery of the fitness equipment. The respective warranty periods for your equipment can be found on its product website.

Repair Costs

According to our choice, there will either be a repair, a replacement of individual damaged parts or a complete replacement. Spare parts, that have to be mounted while assembling the equipment, have to be replaced by the warrantee personally and are not a part of repair. After the expiration of the warranty period, the responsibility for parts costs, repair costs, installation costs and delivery costs lies with the warranty holder.

The terms of use are defined as follows:

- + Home use: solely for private use in private households up to 3 hours per day
- + Semi-professional use: up to 6 hours per day (e. g. rehabilitation centres, hotels, clubs, company gyms)
- + Professional use: more than 6 hours per day (e. g. commercial gyms)

Warranty Service

Within the warranty period, equipment which develops faults as a result of material or manufacturing defects, will be repaired or replaced at our discretion. Ownership of equipment or parts of equipment which have been replaced is transferred to us. The warranty period is not extended nor does a new warranty period begin following repair or replacement under the warranty.

Warranty Conditions

For the warranty to be valid, the following steps must be taken:

Please contact our customer service by email or phone. If the product under warranty has to be sent in for repair, the seller bears costs. After expiry of the warranty, the buyer bears the costs of transport and insurance. If the fault is covered by our warranty, you will receive a new or repaired equipment in return

Warranty claims are invalid in case of damage resulting from:

- + misuse or improper handling
- + environmental influences (moisture, heat, electrical surge, dust, etc.)
- + failure to follow the current safety measures for the equipment
- + failure to follow the operating instructions
- + use of force (e. g. hitting, kicking, falling)
- + interventions which were not carried out by one of our authorized service centres
- + unauthorised repair attempts

Proof of Purchase and Serial Number

Please make sure that you are able to provide the appropriate receipt when claiming on your warranty. So that we can clearly identify the model of your equipment, and for the purposes of our quality control, you will need to give the serial number of your equipment, when contacting the service team. Where possible please have your serial number and your customer number ready when you call our service hotline. It will help us to deal with your request swiftly.

If you cannot find the serial number on your fitness equipment, our service team is at your disposal to offer further information.

Service outside of the Warranty Period

We are also happy to issue an individual cost estimate if there is a problem with your fitness equipment after the warranty has expired, or in cases which do not fall under the terms of the warranty, e. g. normal wear and tear. Please contact our customer service team to find a quick and cost-effective solution to your problem. In such a case you will be responsible for the delivery costs.

Communication

Many problems can be solved just by speaking to us as your specialist supplier. We know how important it is to you as a user of the fitness equipment to have problems solved quickly and simply, so you can enjoy working out with minimal interruption. For that reason, we also want to resolve your queries quickly and in a straightforward manner. Thus, please always keep your customer number and the serial number of the faulty equipment handy.

DE	DK	UK
TECHNIK	TEKNIK OG SERVICE	CUSTOMER CARE
+49 4621 4210-900 +49 4621 4210-698 technik@fitshop.de Öffnungszeiten entnehmen Sie unserer Homepage.	80 90 16 50 +49 4621 4210-945 info@fitshop.dk Abningstider kan findes på hjemmesiden: https://stg.fit/statit7	+44 141 737 2249 or +44 141 876 3972 customercare@fitshop.co.uk You can find the opening hours on our homepage: https://stg.fit/statitd
SERVICE	רח	DE
0800 20 20277 (kostenlos)	FR TECHNIQUE & SERVICE	BE TECHNIQUE & SERVICE
& 04621 4210 - 0	+33 (0) 189 530984	02 732 46 77
info@fitshop.de	+49 4621 42 10 933	+49 4621 4210 933
Öffnungszeiten entnehmen Sie	info@fitshop.fr	info@fitshop.be
unserer Homepage: https://stg.fit/statita	Vous trouverez les heures d'ouverture sur notre site Internet: https://stq.fit/statit4	Vous trouverez les heures d'ouverture sur notre site Internet: https://stg.fit/statit8
		incepsity seguine, searce
ES	NI	INT
ES TECNOLOGÍA Y SERVICIOS	NL TECHNISCHE DIENST & SERVICE	INT TECHNICAL SUPPORT & SERVICE
TECNOLOGÍA Y SERVICIOS	TECHNISCHE DIENST & SERVICE	TECHNICAL SUPPORT & SERVICE
TECNOLOGÍA Y SERVICIOS 911 238 029		TECHNICAL SUPPORT & SERVICE +49 4621 4210-944
TECNOLOGÍA Y SERVICIOS 911 238 029	TECHNISCHE DIENST & SERVICE +31 172 619961	TECHNICAL SUPPORT & SERVICE
TECNOLOGÍA Y SERVICIOS 911 238 029 info@fitshop.es Consulta nuestro horario de apertura en la página web:	TECHNISCHE DIENST & SERVICE +31 172 619961 service@fitshop.nl De openingstijden vindt u op onze homepage:	TECHNICAL SUPPORT & SERVICE +49 4621 4210-944 service-int@fitshop.de You can find the opening hours on our homepage:
TECNOLOGÍA Y SERVICIOS 911 238 029 info@fitshop.es Consulta nuestro horario de apertura en la página web: https://stg.fit/statit5	TECHNISCHE DIENST & SERVICE +31 172 619961 service@fitshop.nl De openingstijden vindt u op onze homepage: https://stg.fit/statit3	TECHNICAL SUPPORT & SERVICE +49 4621 4210-944 service-int@fitshop.de You can find the opening hours on our homepage: https://stg.fit/statita
TECNOLOGÍA Y SERVICIOS 911 238 029 info@fitshop.es Consulta nuestro horario de apertura en la página web: https://stg.fit/statit5	TECHNISCHE DIENST & SERVICE +31 172 619961 service@fitshop.nl De openingstijden vindt u op onze homepage: https://stg.fit/statit3	TECHNICAL SUPPORT & SERVICE +49 4621 4210-944 service-int@fitshop.de You can find the opening hours on our homepage: https://stg.fit/statita CH
TECNOLOGÍA Y SERVICIOS 911 238 029 info@fitshop.es Consulta nuestro horario de apertura en la página web: https://stg.fit/statit5 PL DZIAŁ TECHNICZNY I SERWIS 22 307 43 21 +49 4621 42 10-948	TECHNISCHE DIENST & SERVICE +31 172 619961 service@fitshop.nl De openingstijden vindt u op onze homepage: https://stg.fit/statit3 AT TECHNIK & SERVICE 0800 20 20277 (Freecall) +49 4621 42 10-0	TECHNICAL SUPPORT & SERVICE +49 4621 4210-944 service-int@fitshop.de You can find the opening hours on our homepage: https://stg.fit/statita CH TECHNIK & SERVICE 0800 202 027 +49 4621 42 10-0
TECNOLOGÍA Y SERVICIOS 911 238 029 info@fitshop.es Consulta nuestro horario de apertura en la página web: https://stg.fit/statit5 PL DZIAŁ TECHNICZNY I SERWIS 22 307 43 21	TECHNISCHE DIENST & SERVICE +31 172 619961 service@fitshop.nl De openingstijden vindt u op onze homepage: https://stg.fit/statit3 AT TECHNIK & SERVICE 0800 20 20277 (Freecall)	TECHNICAL SUPPORT & SERVICE +49 4621 4210-944 service-int@fitshop.de You can find the opening hours on our homepage: https://stg.fit/statita CH TECHNIK & SERVICE 0800 202 027

Please find a detailed overview including address and opening hours for all stores of Fitshop UK on the following website:

www.fitshop.co.uk/storelocator

WE LIVE FITNESS

WEBSHOP AND SOCIAL MEDIA

The Fitshop Group is Europe's largest specialist for home fitness equipment with currently 70 stores and one of the world's most renowned online mail order companies for fitness equipment.

Fitshop UK is part of the Fitshop Group. Private customers order via the 25 web shops in the respective national language or have their desired equpiment assembled on site. In addition, the company supplies fitness studios, hotels, sports clubs, companies and physio practices with professional equipment for endurance and strength training.

The Fitshop group offers a wide range of fitness equipment from renowned manufacturers, high-quality in-house developments and comprehensive services, such as a build-up service and sports scientific advice before and after the purchase. The company employs numerous sports scientists, fitness trainers and competitive athletes.

Visit us also on our social media platforms or our blog!

