



IC3

Assembly Instructions

Part Number IC-LFICGIC3-01



Corporate Headquarters

Columbia Centre III, 9525 Bryn Mawr Avenue, Rosemont, IL 60018 • U.S.A.

847.288.3300 • FAX: 847.288.3703

Service phone number: 800.351.3737 (toll-free within U.S.A., Canada)

Global Website: www.lifefitness.com

International Offices

AMERICAS

North America

Life Fitness, LLC

Columbia Centre III
9525 Bryn Mawr Avenue
Rosemont, IL 60018 U.S.A.
Telephone: (847) 288 3300
Service Email:
customersupport@lifefitness.com
Sales/Marketing Email:
commercialsales@lifefitness.com

Brazil

Life Fitness Brasil

Av. Rebouças, 2315
Pinheiros
São Paulo, SP 05401-300
BRAZIL
SAC: 0800 773 8282 option 2
Telephone: +55 (11) 3095 5200 option 2
Service Email: suportebr@lifefitness.com
Sales/Marketing Email:
vendasbr@lifefitness.com

Latin America and Caribbean*

Life Fitness, LLC

Columbia Centre III
9525 Bryn Mawr Avenue
Rosemont, IL 60018 U.S.A.
Telephone: (847) 288 3300
Service Email:
customersupport@lifefitness.com
Sales/Marketing Email:
commercialsales@lifefitness.com

EUROPE, MIDDLE EAST, and AFRICA (EMEA)

Belgium, Netherlands, and Luxemburg

Life Fitness Atlantic BV

Bijdorpplein 25-31
2992 LB Barendrecht
THE NETHERLANDS
+3118064666
Service Email:
service.belux@lifefitness.com
Sales/Marketing Email:
marketing.belux@lifefitness.com

United Kingdom

Life Fitness UK LTD

Unit 109*
Lancaster Way Business Park
Ely, Cambs, CB6 3NX
Telephone: General Office (+44)
1353.666017
Customer Support (+44) 1353.665507
Service Email: uk.support@lifefitness.com
Sales/Marketing Email:
life@lifefitness.com

Germany, Austria, and Switzerland

Life Fitness Europe GMBH

Neuhofweg 9
85716 Unterschleißheim
GERMANY
Telephone:
+49 (0) 89 / 31775166 Germany
+43 (0) 1 / 6157198 Austria
+41 (0) 848 / 000901 Switzerland
Service Email:
kundendienst@lifefitness.com
Sales/Marketing Email:
vertrieb@lifefitness.com

Spain

Life Fitness IBERIA

C/Frederic Mompou 5,1*
08960 Sant Just Desvern Barcelona
SPAIN
Telephone: (+34) 93.672.4660
Service Email:
servicio.tecnico@lifefitness.com
Sales/Marketing Email:
info.iberia@lifefitness.com

All Other EMEA Countries and Distributor Business EMEA*

Life Fitness Atlantic BV

Bijdorpplein 25-31
2992 LB Barendrecht
THE NETHERLANDS
+3118064666
Service Email:
emeaservicesupport@lifefitness.com

ASIA PACIFIC (AP)

Japan

Life Fitness Japan, Ltd

4-17-33 Minami Aoyama 1F/B1F
Minato-ku - Tokyo 107-0062
Japan
Telephone: (+81) 0120.114.482
Fax: (+81) 03-5770-5059
Service Email: service.lfj@lifefitness.com
Sales/Marketing Email:
sales@lifefitnessjapan.com

Hong Kong

Life Fitness Asia Pacific LTD

26/F, Global Trade Square
21 Wong Chuk Hang Road
Wong Chuk Hang
Hong Kong
Telephone: (+852) 25756262
Fax: (+852) 25756894
Service Email: service.hk@lifefitness.com
Sales/Marketing Email:
marketing.hk.asia@lifefitness.com

All Other Asia Pacific countries and distributor business Asia Pacific*

Life Fitness Asia Pacific LTD

26/F, Global Trade Square
21 Wong Chuk Hang Road
Wong Chuk Hang
Hong Kong
Telephone: (+852) 25756262
Fax: (+852) 25756894
Service Email: service.ap@lifefitness.com
Sales/Marketing Email:
marketing.hk.asia@lifefitness.com

*Also check www.lifefitness.com for local representation or distributor/dealer

User and Service Documents Link

<https://lfn.fit/KnowledgeBase>

<https://lfn.fit/SupportDocuments>

Additional information is available online using the links above.

تتوفر معلومات إضافية على الإنترنت باستخدام الرابط أعلاه.

点击上面的链接可在线获取更多信息。

Flere oplysninger er tilgængelige online gennem linket ovenfor.

Bijkomende informatie is online beschikbaar via bovenstaande link.

Vous trouverez plus d'informations en ligne à l'aide du lien ci-dessus.

Zusätzliche Informationen finden Sie online über den oben angegebenen Link.

Ulteriori informazioni sono disponibili online utilizzando il link sopra riportato.

追加情報は上記リンクを使用してオンラインで利用可能です。

상기 링크를 통해 온라인에서 추가 정보를 볼 수 있습니다.

Informações adicionais estão disponíveis on-line, através do link acima.

Дополнительная информация доступна в интернете по ссылке, указанной выше.

Mediante el enlace anterior podrá acceder a información adicional en línea.

Ytterligare information finns online genom att använda länken ovan.

İnternet üzerinden daha fazla bilgi edinmek için yukarıdaki bağlantıyı kullanabilirsiniz.

هناك معلومات إضافية متاحة على الإنترنت باستخدام الرابط أعلاه.

Informazio osagarria eskuragarri dago goiko estekaren bidez.

Допълнителна информация можете да намерите онлайн, като използвате връзката по-горе.

Mitjançant l'enllaç anterior podreu accedir a informació addicional en línia.

使用上面的連結線上提供額外資訊。

Dodatne informacije možete pronaći na internetu sljedeći vezu iznad.

ከላይ የተቀመጠውን አገናኝ(ሊንክ) በመጠቀም መረጃዎች እንላይን ያገኛሉ፡፡

Lisätietoja on saatavissa verkosta käyttämällä yllä olevaa linkkiä.

Wubetumi anya nsem afoforo aka ho wə websait so denam asem a ewə atifi ho a wubemia so so.

Πρόσθετες πληροφορίες είναι διαθέσιμες online χρησιμοποιώντας το σύνδεσμο παραπάνω.

מידע נוסף זמין באינטרנט באמצעות הקישור לעיל.

További információ elérhető online, a fenti hivatkozás segítségével.

Viðbótarupplýsingar eru fáanlegar á netinu með því að smella á tengilinn hér fyrir ofan.

Plus indicium per superum situm potes invenire.

മുകളിലുള്ള ലിങ്ക് ഉപയോഗിച്ച് ഓൺലൈനിൽ കൂടുതൽ വിവരങ്ങൾ ലഭ്യമാണ്.

Ytterligere informasjon er tilgjengelig på nettet via linken ovenfor.

Dodatkowe informacje są dostępne online pod powyższym odnośnikiem.

Informações adicionais estão disponíveis online a usar o link acima.

Informații suplimentare sunt disponibile online, utilizând link-ul de mai sus.

Dodatne informacije dostupne su na mreži putem gornjeg linka.

Ďalšie informácie sú dostupné online na vyššie uvedenom odkaze.

Table of Contents

Getting Started

Overview.....	4
Safety Instructions.....	4
Moving the Indoor Cycle.....	6
Leveling the Indoor Cycle.....	7

Changes in Warranty Not Authorized.....	30
Effects of State Laws.....	30
Warranty Information.....	31

Product Overview

Product Features.....	8
Adjusting the Indoor Cycle.....	8
Using the Pop Pin Knobs.....	9
Using the Thumb Lever.....	9
Adjust Seat Height.....	10
Adjust Seat Horizontally.....	10
Handlebar Positioning.....	11
Adjust Resistance.....	11
Emergency Brake.....	12

Assembly

Tools Required.....	13
Assembly Procedure.....	13

Specifications

Specifications.....	22
---------------------	----

Service and Technical Data

Approved and Compatible Cleaners.....	23
Maintenance.....	23
How To's.....	27
Spare Parts.....	28
Spare Parts - Stabilizer.....	29

Warranty

What is Covered.....	30
Who is Covered.....	30
How Long It is Covered.....	30
Who Pays Transportation and Insurance For Service.....	30
What We Will Do To Correct Covered Defects.....	30
What is Not Covered.....	30
What You Must Do.....	30
How to Get Parts and Service.....	30
Exclusive Warranty.....	30

Life Fitness® is a registered trademark.

Gym Wipes® is a registered trademark of the 2XL Corporation. PureGreen 24 is a trademark of Pure Green. Polar® is a registered trademark of Polar Electro Inc.

© Copyright 2024, Life Fitness, LLC. All Rights Reserved. Life Fitness, Hammer Strength, Cybex, ICG and SCIFIT are registered trademarks of Life Fitness, LLC and its affiliated companies and subsidiaries. Disclaimer: Images and specifications are current as of the date of publication and are subject to change.

Columbia Center III - 9525 Bryn Mawr Ave., Rosemont, IL 60018 • 847-288-3300

www.lifefitness.com • Part Number IC-LFICGIC3-01 • REV AA • 2024

1. Getting Started

Overview

The ICG Indoor Cycle offers an impressive array of features to improve cardiovascular fitness, tone muscles and develop endurance. This high level of reliability can however only be ensured with regular care and maintenance. Adhering to the maintenance procedures outlined in this manual will ensure a maximized stability and prolonged lifespan in return for minimal maintenance effort. This will guarantee long-standing, interruption-free operation.

Safety Instructions



CAUTION: Read all precautions and instructions in this manual before you start using the indoor cycle. Keep this manual for future reference. Improper assembly, use or maintenance can void the warranty terms.

Any service, other than cleaning or user maintenance, must be performed by an authorized service representative. There are no user-serviceable parts.



WARNING: To reduce the risk of serious injury due to improper use of the equipment, carefully read and adhere to the following important precautions and information before operating the indoor cycle.



WARNING: It is the responsibility of the owner to ensure that all users are informed of all warnings and precautions for proper use and are only authorized to use the bike independently after being successfully briefed by a qualified trainer or instructor.



WARNING: Do not operate the bike until it has been properly assembled and inspected as described in this manual.



WARNING: Keep the indoor cycle indoors, away from moisture and dust. Do not place the indoor cycle outdoors in a garage or covered patio or near water or pools. Operating temperature of the indoor cycle has to be between 15°C ~ 40°C Celsius (59°F~104°F) at a maximum humidity of 65%.



WARNING: Always place the bike on a stable, level surface. If the bike is to be placed on a hardwood floor or carpet, it is recommended to place a floor mat beneath the bike, to protect the floor from becoming damaged.



WARNING: The level of safety of the Indoor Cycle can only be guaranteed if it is regularly checked for possible damage as well as wear and tear (e.g. fixing points, E-Brake, Pedals, toe straps, etc.). Consult an authorized service provider or the manufacturer direct to ensure the regular inspections are properly carried out.



WARNING: Carry out all maintenance, care and service procedures as described in this manual on a regular basis. Defective parts must be replaced immediately, and the device must not be used until the repairs have been carried out. Only use original parts from the manufacturer. Repairs must only be carried out by manufacturer authorized service technicians.



WARNING: Unsupervised children should be always kept away from the training device.



WARNING: The training equipment can be used by children aged from 14 years and above and persons with lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children under 14 years of age and Persons with reduced physical, sensory or mental capabilities are prohibited from using the training equipment. Cleaning and user maintenance shall not be carried out by children without supervision. Children shall not play with the appliance.



WARNING: The indoor cycle must not be used by persons exceeding weight of 330 lbs. (150 kg.).



WARNING: Always wear appropriate tight-fitting cycling or athletic attire and sturdy shoes, preferably cycling shoes, while operating the bike. Unfastened shoelaces may become caught in the drive system and lead to injury.



WARNING: The bike does not have an independently moving flywheel. The pedals will continue to move with the flywheel until the flywheel stops. The movement can only be stopped by using the emergency brake or by reducing the pedaling frequency in a controlled manner. Always ride with resistance load to ensure that your pedaling motion is controlled. Do not adjust handlebar or seat during workout. Do not pedal backwards.



WARNING: If you feel physical discomfort or dizziness, stop training and consult a physician. If the user requires medication that has effect on their performance capabilities and/or cardiovascular system, it is imperative that they consult a doctor in order to adjust the personal entries accordingly.



WARNING: All data shown on the display, especially the Watt values generated by the integrated power sensor serve merely as information and to help guide training. Only exercise within your physical limitations.



WARNING: If you have pre-existing health problems or a disability, it is recommended that you consult your physician, to find the training method which is best suited to you. Incorrect or extensive training can result in serious health injuries. The manufacturer expressly assumes no responsibility for health risks, personal injury, property damage or consequential damages sustained by or through the use of this device, unless it is a case of consequential damage which can be traced back to faulty material and/or manufacturing, and which come under the responsibility of the manufacturer.



WARNING: The division of the training zones for power or heart rate-oriented training is based on an average person's performance. The zones may sometimes vary dramatically depending on the nature of the training, the state of your health (e.g. whether you are taking any medications) and your physical capabilities. It is recommended to always work out sensible training parameters for your own personal training under medical supervision, and to plan your personal training based on this data.



WARNING: Do not exercise beyond your ability.



WARNING: If you feel physical discomfort or dizziness, stop training, and consult a physician.



WARNING: Color zones are for guidance only.




WARNING: If the user requires medication that influences their performance capabilities and / or cardiovascular system, it is imperative that they consult a doctor in order to adjust the personal entries accordingly.

Moving the Indoor Cycle

It is recommended that two people move the Indoor Cycle. To prevent accidents and damage to the plug-in sockets of the handlebars, it is necessary to firmly fix the vertical handlebar adjustment before the cycle is moved. Take extra care when moving the Indoor Cycle over uneven surfaces. A second person is advisable here, to prevent the cycle from tilting to one side.


 **WARNING:** Allow a minimum safety distance of 24" (60 cm) inches away from equipment, objects or walls as shown below.



Item	Description	Qty
1	24" (60 cm)	4

Leveling the Indoor Cycle

Check the stability of the Indoor Cycle where it is to be operated and if necessary, adjust the leveling feet underneath the front or rear stabilizers to ensure the desired stability.




Item	Description	Qty
1	Leveling Feet	4

 **WARNING:** Do not unscrew the leveling feet more than 0.4" (10 mm). The free-standing indoor cycle shall only be installed and operated on a stable and leveled floor.

2. Product Overview

Product Features



Item	Description	Qty.
1	Handlebar	1
2	Resistance Dial / Emergency Brake	1
3	Adjustment Knob for Vertical Handlebar Adjustment	1
4	Flywheel	1
5	Transport Wheels	2
6	Dual Sided SPD Pedal	2
7	Leveling Feet	4
8	Shroud	1
9	Adjustment Knob for Vertical Seat Adjustment	1
10	Thumb Lever for Horizontal Seat Adjustment	1
11	Seat	1

IMPORTANT: The production code on the tag plate is located on the side of the frame tube of the Indoor Cycle. Please enter this production code into the care and maintenance lists. It is a strict requirement to provide the production code in all warranty claims.

Adjusting the Indoor Cycle

The Indoor Cycle can be very easily adjusted, depending on the requirements of various user groups. This enables maximum riding comfort to be ensured whilst achieving optimal training results. The configurations described in the

following paragraphs demonstrate just a few of the most often used adjustment variations of which the Indoor Cycle is capable. It is up to the user to adjust the Indoor Cycle to a riding position best suited to their requirements.


 **WARNING:** Do not adjust the seat or handlebar during use of the indoor cycle. Ensure that the Pop Pin knobs used for the height adjustment of the handlebar and seat are properly tightened and the thumb lever for horizontal adjustment of the seat are closed before you sit on the bike. Always step off the bike when adjusting the handlebars and / or seat.

Using the Pop Pin Knobs

The height of the handlebars and seat must be adjusted to your specific requirements.

1. Turn the knob 1/2 turn in the counterclockwise direction.

Handlebar shown for reference




Item	Description	Qty
1	Turn Knob Counterclockwise	1
2	Handlebar	1
3	Pull Knob to Disengage	1

2. Hold the handlebars / seat to prevent it from falling.
3. Pull the knob to disengage pop pin knob.
4. While pulling the knob adjust the handlebar height. The pop pin knob will snap into the selected position.
5. Tighten the pop pin knob in the clockwise direction.

Using the Thumb Lever

The thumb lever is used to lock the horizontal position of the seat.

1. To loosen the seat slider for adjustment, turn the thumb lever 90 degrees counterclockwise. to the open position.




Item	Description	Qty
1	Thumb Lever	1
2	Closed	1
3	Open	1

2. Adjust the seat position as needed and turn the thumb lever 90 degrees in the clockwise direction to the closed position. Apply enough pressure to the thumb lever, until the seat is fixed.

Adjust Seat Height

1. Sit on the seat and ensure that your hip is not tilted to one side when the pedal has assumed the position as shown below.



Item	Description	Qty
1	Vertical Seat Adjustment	1
2	Vertical Handlebar Adjustment	1

2. Place your shoes in the toe clips (cages) on the pedals, or in the SPD cleats if you are using cycling shoes.
3. Start pedaling slowly, until the pedal has reached the position as shown above.
4. The seat height should be adjusted so that your knees are always slightly bent when the pedal is at its lowest position without dropping your hip to one side.

NOTE: When standing next to the bike, the upper edge of the seat should be a hand 's width / four fingers below your iliac crest.




CAUTION: Avoid cycling with your knees fully extended or your hip tilted to one side.

Adjust Seat Horizontally

Properly positioning the seat horizontally is very important to avoid injury to the knees.

1. Sit on the seat and move the pedals until the crank arms are in the horizontal position.



Item	Description	Qty
1	Knee	1
2	Center of Pedal	1


2. The knee of your forward-facing leg should be positioned directly above the center of the pedal. If this does not correspond to your bike 's setting, align the horizontal seat adjustment to the front or rear to attain this seat position.



WARNING: Do not adjust seat and handlebar during exercise. Ensure that the pop-pin-knobs used for the height adjustment of the handlebar and seat are properly tightened and the thumb levers for horizontal adjustment are closed before you sit on the bike. Always step off the bike when adjusting the handlebars and / or seat.

Handlebar Positioning

Set the top of the handlebars to approximately the same height as the seat. If your knees touch the handlebars or if you experience back discomfort when pedaling in the standing riding position for extended periods, the handlebars should be adjusted slightly higher.



Item	Description	Qty
1	Seat	1
2	Top of Handlebars	1


It is recommended to change hand positions frequently during extended workouts to minimize one-sided and monotonous exertions on your muscles, ligaments and joints.

 **WARNING:** Do not adjust seat and handlebar during exercise. Ensure that the pop-pin-knobs used for the height adjustment of the handlebar and seat are properly tightened and the thumb lever for horizontal adjustment is closed before you sit on the bike. Always step off the bike when adjusting the handlebars and / or seat.

Adjust Resistance

The resistance adjustment can be set precisely and regulated in fine increments according to the requirements of the cyclist using the resistance adjustment knob with a range of motion of 300°. The resistance in % (where 0% is no resistance and 100% is maximum resistance) is also displayed on the Indoor Cycle computer display.

1. To increase the resistance, turn the resistance adjustment knob clockwise.




Item	Description	Qty
1	Decrease Resistance	1
2	Increase Resistance	1

2. To decrease the resistance, turn it counterclockwise.

The resistance will increase with the pedaling frequency due to the magnetic brake system of the indoor cycle.

Emergency Brake

To stop the flywheel in the event of an emergency, push down on the resistance knob.



Item	Description	Qty
1	Push Down	1
2	Resistance Knob	1

NOTE: During training, make sure your shoes are placed in the toe clips (cages) provided or if you are using cycling shoes, that they are connected with the SPD cleats.

If the emergency brake has been activated, it can only be disengaged again when the flywheel has come to a complete standstill and the pressure has been removed from the pedals.



WARNING: For your safety, always make sure you pedal in a controlled manner and adjust your pedaling frequency to your cycling capabilities.



WARNING: Never pedal backwards, as this can loosen the pedals and the crank arm bolts which may lead to them detaching themselves from the indoor cycle. The indoor cycle does not have a freewheel. The pedals are firmly connected to the flywheel, and they will not stop independently when the pedaling motion is interrupted. To stop the bike after a workout, always control your pedaling motion by slowly decreasing the pedaling cadence in controlled manner until the pedals and flywheel are completely stopped.

3. Assembly

Tools Required

- #2 Phillips screwdriver
- 5 mm Allen wrench
- 5 mm Allen key socket
- 13 mm socket wrench
- 17 mm socket wrench
- 13 mm open end wrench
- 17 mm open end wrench
- 15 mm pedal wrench
- Torque wrench



WARNING: Avoid high fluctuations in temperature whilst transporting the bike from the store to the installation site. If there are nevertheless large fluctuations in temperature, please allow the bike to acclimatize to the surrounding temperature before proceeding with assembly.


Assembly Procedure

Two people are recommended for this procedure.

TIP: Read and understand all instructions thoroughly before assembling this unit. Check all items carefully. If there is damage, see the Customer Service section of this manual for proper procedure to return, replace, or reorder parts.

Install Front Stabilizer Assembly

Install bolts, washers, and rubber gasket securing front stabilizer assembly to frame using a 17 mm socket wrench.




Item	Description	Qty.
1	Front Stabilizer	1
2	Washer, M10	2
3	Bolt, M10 x 60	2
4	Rubber Gasket	1



Tighten hardware to 5.2 ft-lb (7 Nm).

Install Rear Stabilizer Assembly

Install bolts, washers, cap nuts, and rubber gasket securing rear stabilizer assembly to frame using a 17 mm socket wrench.



Item	Description	Qty.
1	Cap Nut, M10	2
2	Washer, M10	4
3	Nylon Washer, M10	2
4	Rubber Gasket	1
5	Rear Stabilizer	1
6	Bolt, M10 x 60	2


IMPORTANT: Make sure upper washers are installed correctly with the metal washer on top of nylon washer.



Tighten hardware to 5.2 ft-lb (7 Nm).

Install Handlebar Assembly

1. Turn the pop pin knob 1/2 turn in the counterclockwise direction.




Item	Description	Qty.
1	Handlebar Stem	1
2	Pop Pin Knob	1



Tighten hardware to 5.2 ft-lb (7 Nm).


2. Hold the handlebar stem to prevent it from falling.
3. Pull the pop pin knob to disengage the pin.

4. While pulling the pop pin knob lift the handlebar stem to the number 3 position and the pop pin knob will engage in the handlebar stem.




Item	Description	Qty.
1	Number 3 Position	1
2	Pop Pin Knob	1

5. Lock the handlebar stem into position by turning the pop pin knob in the clockwise direction hand tight.
6. Insert the handlebar assembly into the tube of the handlebar stem.



Item	Description	Qty.
1	Handlebar Assembly	1
2	Handlebar Stem	1

7. Lightly fasten all 6 bolts into the threads of the handlebar using a 5 mm Allen wrench.




Item	Description	Qty.
1	Forward Facing Bolts, M8 x 12	2
2	Side Bolts, M8 x 12	4

8. Torque the bolts starting with the forward-facing bolts then the side bolts.




Tighten hardware to 13.3 ft-lb (18 Nm).

9. Connect the wires from the base to the handlebars.



Item	Description	Qty.
1	Base Wires	1
2	Handlebar Wires	1


10. Tuck the connected wires into the slot. Carefully position the wires in the slot of the cap and carefully press the plastic cap until it snaps into position.



Item	Description	Qty.
1	Connected Wires	1
2	Plastic Cap	1

Install Seat

- 1. Install seat clamp onto seat post.




Item	Description	Qty.
1	Seat Clamp	1
2	Seat Post	1



Tighten hardware to 5.2 ft-lb (7 Nm).


- 2. Tighten seat clamp bolts evenly using a 13 mm socket wrench. Make sure seat is level and straight.



Tighten hardware to 18.5 ft-lb (25 Nm).


Install Batteries

1. Remove two screws securing battery cover using a Phillips screwdriver.



Item	Description	Qty.
1	Tab	1
2	Battery Cover	1
3	Screw	2

2. Remove battery cover.
3. Remove tab from battery compartment.
4. Install two batteries in the orientation shown. Batteries type is D cell (LR20) 1.5 VDC.




5. Install two screws securing battery cover using a Phillips screwdriver.

Install Pedals

The pedal threads are coated with TufLok® to prevent them from becoming loose during use. If pedals are loosened or removed after initial assembly, we recommend using medium-strength Loctite® #243 when reassembling.

1. Install right pedal into right crank arm.



Item	Description	Qty.
1	Right Crank Arm	1
2	Right Pedal	1




WARNING: The pedal on the right side of the bike must be assembled and torqued in the clockwise direction. The right pedal and crank arm are marked with a Blue sticker.



Tighten hardware to 41 ft-lb (55 Nm).

2. Install right pedal into right crank arm.



Item	Description	Qty.
1	Left Crank Arm	1
2	Left Pedal	1




WARNING: The pedal on the left side of the bike must be assembled and torqued in the counterclockwise direction. The left pedal and crank arm are marked with a Yellow sticker.



Tighten hardware to 41 ft-lb (55 Nm).

Warning Label Placement

Warning labels on the bikes must be replaced by warning labels in your language during the assembly process.



1	2
WARNING 1. Misuse of this machine may result in serious injury. 2. Read user manual prior to use and follow all warnings and instructions. 3. Replace label if damaged, illegible or removed. 4. Keep children away. 5. Use only a solid, level surface. 6. Maximum user weight is 150kg/331lbs. 7. Spinning pedals can cause injury. 8. This bike does not free-wheel. 9. Pedal speed should be reduced in a controlled manner. WARNING — Use the stationary training equipment in a supervised environment.	WARNING After deploying the E-Brake: 1. Ensure flywheel is at a full stop. 2. Release brake pressure. 3. Release pressure on the pedals. 4. Begin pedaling. Don't pedal backwards! Limited E-brake functionality while pedaling backwards.

Installation and Setup

Instructions stated in this manual must be performed during initial installation of the Indoor Cycle to ensure optimal performance and a long lifespan. Read and follow the following instructions carefully. If the Indoor Cycles are not installed and configured as described, the components may be subjected to excessive wear and tear and the bike may become damaged.

NOTE: Lubricants are required for some maintenance procedures.

Only use an acid-free and solvent-free spray lubricant and white lithium grease.

1. Make sure the bike is level. If bike rocks on the floor, turn the leveling feet underneath the front and / or rear stabilizer until the rocking motion is eliminated. Make sure that the leveling feet are not screwed out further than 0.4" (10 mm).
2. Verify emergency brake function to make sure that it is working properly.
3. Check that both crank arm Allen bolts, with which the cranks (on the right and left side of the bottom bracket) are fastened, and secure (tightening torque 44 ft. lb. (60 Nm)). These bolts are provided with TufLok at the factory to prevent them from becoming loose during use. If the bolts become loose, we recommend applying medium-strength Loctite® #243 and then reattaching the crank fixing bolts with a tightening torque of 44 ft. lb. (60 Nm).
4. Wipe down bike frame with a rag moistened with acid-free and solvent-free spray lubricant.
5. Some parts of the bike may become loose during shipment. Check crank arms and all exposed bolts and nuts, and make sure that they are all secure and properly tightened.

Customer Service

1. Provide the customer with basic maintenance instructions and direct them to detailed maintenance instructions.
2. Have the sign-off sheet for the manual, explanation of maintenance procedures and verification of impeccable condition of the bikes confirmed by the customer when handing over the goods. A copy of the confirmation should be counter signed by yourself and a copy of the confirmation should also be left with the customer.
3. Repairs must only be carried out by manufacturer authorized service technicians.

4. Specifications

Specifications

The IC3 Bike is manufactured, according to EN ISO 20957-1 and EN ISO 20957-10, a Class S product for use in a controlled environment such as sports or fitness facilities under the supervision of a trainer.

Life Fitness hereby declares that the radio equipment type LCD console complies with Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following internet address: www.indoorcycling.com/conformity/

Weight of bike:	44 kg / 97 lbs.
Max user weight:	150 kg / 330 lbs.
User height:	Suitable for users between approx. 155 and 215 cm / 5'1 - 7'
Required footprint:	123 cm x 53 cm / 48" x 21"
Max seat height	121 cm / 47"
Max handlebar height:	112 cm / 44"
Bluetooth le 4.2:	Frequency: 2.4 ghz - 2.48 ghz
Transmit power:	0 - 4 dbm
Ant: frequency:	2.4 ghz - 2.48 ghz
Transmit power:	0 - 4 dbm
Batteries:	2 - D cell (LR20) batteries 1.5 VDC

5. Service and Technical Data

Approved and Compatible Cleaners

Two preferred cleaners have been approved by reliability experts: PureGreen 24 and Gym Wipes. Both cleaners will safely and effectively remove dirt, grime and sweat from equipment. PureGreen 24 and the Antibacterial Force formula of Gym Wipes are both disinfectants that are effective against MRSA and H1N1.

PureGreen 24 is available in a spray which is convenient for gym staff to use. Apply the spray to a microfiber cloth and wipe down the equipment. Use PureGreen 24 on the equipment for at least 2 minutes for general disinfection purposes and at least 10 minutes for fungus and viral control.

Gym Wipes are large, durable pre-moistened wipes to use on the equipment before and after workouts. Use Gym Wipes on the equipment for at least 2 minutes for general disinfection purposes.

Contact Customer Support Services to order these cleaners (1-800-351-3737 or email: customersupport@lifefitness.com).

Mild soap and water or a mild non-abrasive household cleaner can also be used to clean the display and all exterior surfaces. Use a soft microfiber cloth only. Apply the cleaner to the microfiber cloth before cleaning. DO NOT use ammonia or acid based cleaners. DO NOT use abrasive cleaners. DO NOT use paper towels. DO NOT apply cleaners directly to the equipment surfaces.

Maintenance

Preventive Maintenance



WARNING: Carefully observe the following instructions.

- The maintenance and care procedures must be performed in the regularity set out, to ensure maximum operating safety and lifespan.
- Irregularly observed maintenance and care procedures will lead to increased wear to the product and will void the warranty.
- If you have any further questions on this topic, contact our technical support.
- Only use the acid-free and solvent-free maintenance and care agent recommended by us to prevent damage to components of the Indoor Cycle.


Daily Maintenance

1. Make sure that the Indoor Cycle is leveled and does not rock.
2. Cleaning: The Indoor Cycle must be regularly cleaned after each use for reasons of hygiene.
 - Ensure that there are sufficient soft cloths or paper towels and maintenance and disinfection agent available.
 - First disinfect the seat and handlebars with a suitable agent and then wipe all bodily residues off the entire Indoor Cycle.

Weekly Maintenance

Cleaning: Depending on how often the Indoor Cycle is used, it must be extensively cleaned once a week.
Spray a maintenance spray onto a soft cloth and clean all plastic parts, the entire flywheel, exposed framework parts including stabilizers and the plastic casing.

 **WARNING:** Never spray maintenance spray or anything else directly onto the flywheel. Never pedal the indoor cycle to ease cleaning, as this could cause the drive belt to slip during use, reduce braking performance or damage internal components.




Bi-Weekly Maintenance

Emergency Brake

To ensure operating safety, the emergency brake must be regularly checked to make sure it is functioning properly.

- 1. Completely press down the resistance knob whilst pedaling.




Item	Description	Qty
1	Push Down	1
2	Resistance Knob	1

- 2. When functioning optimally, it should produce an immediate braking effect and bring the flywheel to a complete standstill.
- 3. The flywheel is only released again by the emergency braking function after coming to a complete standstill and when the pressure is removed from the pedals.

Seat Adjustments


To maintain the easy adjustment, the vertical and horizontal seat posts must be regularly cleaned and lubricated.

- 1. Position the vertical seat post in the uppermost position.



Item	Description	Qty
1	Vertical Seat Post	1

- 2. Spray with maintenance spray and rub down the entire exterior surfaces including the horizontal post with a soft cloth.
- 3. Clean sweat residues off the contact surfaces of the horizontal seat post beforehand and if necessary, apply a small amount of lithium grease.




Item	Description	Qty
1	Horizontal Seat Post	1

Handlebars

To maintain the easy adjustment of the handlebar stem, it must be regularly cleaned and lubricated.

- 1. Position the handlebars in the uppermost position.




Item	Description	Qty
1	Handlebar Post	1

- 2. Spray the handlebar posts with maintenance spray and rub down the entire exterior surfaces including the horizontal post with a soft cloth.
- 3. Clean sweat residues off the contact surfaces.

Monthly Maintenance


Connecting Elements

During regular maintenance and care procedures, all bolts, nuts etc. on the Indoor Cycle must be checked to ensure that they are properly tightened and function correctly. Parts showing wear or damage (seat, pedal teeth, pedals, SPD system) must be replaced.



Pop Pin Lubrication

Pop pin knobs are located on the vertical adjustment of the handlebar and seat. To ensure the easy adjustment of the vertical handlebar and seat posts, the threads on the pop-pin-knob must be lubricated. We recommend lithium grease.



Item	Description	Qty
1	Pop Pin Knob	1
2	Threads	1

Maintenance Schedule and Checklist

Activity	Rotation
Feet leveling, disinfection and cleaning of the bike	Daily
Detailed cleaning of the entire bike	Weekly
Check emergency brake function	Bi-weekly
Clean and lubricate seat and handlebar sliders / stems	Bi-weekly
Check all connections and fixings	Monthly
Vertically adjusting the handlebar and seat	Monthly

Examples of Maintenance Plan for In-House Service Technicians

Weekly maintenance checklist

Bike no.	Production code	Observations	Actions taken	Result	Name / date

Bi-weekly maintenance checklist

Bike no.	Production code	Observations	Actions taken	Result	Name / date

Monthly maintenance checklist

Bike no.	Production code	Observations	Actions taken	Result	Name / date

How To's


Knowledge Base

See <https://lfn.fit/KnowledgeBase> for more detailed information.

How to Obtain Product Service


1. Verify the symptom and review the operating instructions. The problem may be unfamiliarity with the product and its features and workouts.
2. Locate and write down the serial number of the unit which is located on the top right of the front stabilizer.
3. Contact Customer Support Services at <http://www.lifefitness.com>.

Spare Parts



Item	Part Number	Description	Qty
1	110-01-00113-01	Handlebar Including Console Bracket	1
2	320-00-00019-01	ICG LCD Coach-by-color Connect Console	1
3	110-01-00122-01	Handlebar Mounting Kit	1
4	120-01-00076-01	Sport Seat Black Including Seat Clamp	1
5	150-01-00005-04	Combination Pedal Set, SPD Compatible	1

Spare Parts - Stabilizer



Item	Part Number	Description	Qty
1	140-02-00024-01	Front Stabilizer Weldment	1
2	140-01-00003-01	Transportation Wheel Kit	2
3	140-03-00020-01	End Cap	4
4	190-01-00027-01	Leveling Feet, Rubber 75° shore	4
5	140-02-00025-01	Rear Stabilizer Weldment	1
6	140-01-00028-01	Front And Rear Stabilizer Mounting Hardware	1

6. Warranty

What is Covered

This Life Fitness Family of Brands commercial exercise equipment product is warranted to be free of all defects in material and workmanship.

Who is Covered

The original purchaser or any person receiving the product as a gift from the original purchaser. Warranty will be voided on subsequent transfers.

How Long It is Covered

All coverage is provided by specific Product according to the guidelines listed in Warranty Information.

Who Pays Transportation and Insurance For Service

If the Product or any covered part must be returned to a service facility for repairs, We, Life Fitness Family of Brands, will pay all transportation and insurance charges for the first year. You are responsible for transportation and insurance charge after the first year.

What We Will Do To Correct Covered Defects

We will ship to you any new or rebuilt replacement part or component, or at our option, replace the Product. Such replacement parts are warranted for the remaining portion of the original warranty period.

What is Not Covered

Any failures or damage caused by unauthorized service, misuse, accident, negligence, improper assembly or installation, debris resulting from any construction activities in the Product's environment, rust or corrosion as a result of the Product's location, alterations or modifications without our written authorization, or by failure on your part to use, operate and maintain the Product as set out in your Operation Manual.

All terms of this warranty are void if this product is moved beyond the continental borders of the United States of America (excluding Alaska, Hawaii and Canada) and are then subject to the terms provided by that country's local authorized Life Fitness Family of Brands representative.

What You Must Do

Retain proof of purchase. use, operate and maintain the Product as specified in the Manual; notify the place of purchase of any defect within 10 days after discovery of the defect; if instructed, return any defective part for replacement or, if necessary, the entire Product for repair. ICG reserves the right to decide whether or not a product is to be returned for repair.

How to Get Parts and Service

Refer to the Corporate Headquarters section of this manual for your local service contact information. Reference your name, address and the serial number of your Product (consoles and frames may have different serial numbers). They will tell you how to get a replacement part, or, if necessary, arrange for service where your Product is located.

Exclusive Warranty

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, AND ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART. We neither assume nor authorize any person to assume for us any other obligation or liability concerning the sale of this Product. Under no circumstances shall we be liable under this warranty, or otherwise, of any damage to any person or property, including any lost profits or lost savings, for any special, indirect, secondary, incidental or consequential damages of any nature arising out of the use of or inability to use this Product. Some states do not allow the exclusion or limitation of implied warranties or of liability for incidental or consequential damages, so the above limitations or exclusions may not apply to you.

Changes in Warranty Not Authorized

No one is authorized to change, modify or extend the terms of this limited warranty.

Effects of State Laws

This warranty gives you specific legal rights, and you may have other rights which vary from state to state and country by country.

Warranty Information

5 Years Warranty

Frame construction and welding

3 Years Warranty

Powder coating (paint cracks, corrosion)

handlebar and seat post assembly

Aluminum parts and PVC coating

Belt drive system

Bottom bracket assembly

Flywheel and hub assembly

Crank

Pedals (excluded binding systems and straps)

Insert sleeves for handlebars and seat post

Brake system

Leveling feet

Shroud and top covers

1 Year Warranty: Electronic Components

Computer, cable harness, PCB's and sensors, generator

Lithium polymer (lipo) battery

6 Months

Warranties outside the U.S. may vary.

